

MARS GLOBAL SURVEYOR



Mars Orbiter Laser Altimeter

**MOLA PRECISION EXPERIMENT DATA RECORD
SOFTWARE INTERFACE SPECIFICATION
(MOLA PEDR SIS)**

MGS-M-MOLA-3-PEDR-L1A-V1.0

**Version 2.7,
December 12, 1998**

**NASA Goddard Space Flight Center
Greenbelt, MD 20771**

MARS GLOBAL SURVEYOR



Mars Orbiter Laser Altimeter

**MOLA PRECISION EXPERIMENT DATA RECORD
SOFTWARE INTERFACE SPECIFICATION
(MOLAPEDR SIS)**

MGS-M-MOLA-3-PEDR-L1A-V1.0

Submitted: _____
Gregory A. Neumann
MOLA Science Team
Date

Concurred: _____
Maria Zuber
MOLA Deputy Principal Investigator
Date

Approved: _____
David E. Smith
MOLA Principal Investigator
Date

**MARS ORBITER LASER ALTIMETER
PRECISION EXPERIMENT DATA RECORD
SOFTWARE INTERFACE SPECIFICATION
(MOLA PEDR SIS)**

Document and Change Control Log			
Date	Version	Section	Status
04/01/97	1.0	all	Released for MGS
07/23/97	1.1	Section 4.3.2 Table 1 Table 2 Appendix C	Updated for PEDR format changes
07/23/97	1.1	Appendix C	Incorrect start bytes and descriptions were corrected in the format files (unmarked)
01/30/98	2.0	all	revised for contingency science
09/24/98	2.5	Section 4.3.2	revised format definitions
10/01/98	2.6	Tables 1 and 2; Appendix C	delta-spacecraft position replaces SC X-Y-Z coordinates at frame mid-point
10/12/98		Table 2, Appendix C	frame local time defined as subsolar longitude in radians
12/12/98	2.7	Tables 1 and 2; Appendix C	delta-latlon/delta-r and xover residual replaces ground X-Y-Z coordinates at frame-midpoint.

Section	Table of Contents	Page
1.0	Introduction	1
1.1	Purpose	1
1.2	Scope	1
1.3	Applicable Documents	1
1.4	Functional Description	2
1.4.1	Data Content Summary	2
1.4.2	Source and Transfer Method	2
1.4.3	Recipients and Utilization	2
1.4.4	Pertinent Relationships with Other Interfaces	2
1.5	Assumptions and Constraints	2
2.0	Environment	3
2.1	Hardware Characteristics and Limitations	3
2.2	Interface Medium and Characteristics	3
2.3	Failure Protection, Detection, and Recovery Features	3
2.3.1	Backup Requirements	3
2.3.2	Security / Integrity Measures	3
2.4	End-Of-File (or Medium) Conventions	3
3.0	Access	4
3.1	Access Tools	4
3.2	Input / Output Protocol	4
3.3	Timing and Sequencing Characteristics	4
3.4	PDB Information	4
4.0	Detailed Interface Specifications	5
4.1	Labeling and Identification	5
4.2	Structure and Organization Overview	5
4.3	Substructure Definition and Format	5
4.3.1	Header / Trailer Description Details	5
4.3.2	Data Description Details	6
4.4	Volume, Size, and Frequency Estimates	7

List of Figures		Page
1	PEDR Data Product Structure and Organization	8

List of Tables		Page
1	PEDR Data Product Record Format	9
2	PEDR Data Product Record Contents Description	11
3	PEDR Data Product Subcommutated Data Format	16

List of Appendices		Page
Appendix A	Acronyms	18
Appendix B	Precision Experiment Data Record Catalog Files	19
Appendix C	SFDU Labels and Format Files	20
Appendix C.1	SFDU Labels and Catalog Header	20
Appendix C.2	Contents of the PEDRSEC1 . FMT Format File	23
Appendix C.3	Contents of the PEDRENG1 . FMT Format File	33
Appendix C.4	Contents of the PEDRENG2 . FMT Format File	36
Appendix C.5	Contents of the PEDRENG3 . FMT Format File	39
Appendix C.6	Contents of the PEDRENG4 . FMT Format File	42
Appendix C.7	Contents of the PEDRENG5 . FMT Format File	43
Appendix C.8	Contents of the PEDRENG6 . FMT Format File	45
Appendix C.9	Contents of the PEDRENG7 . FMT Format File	46
Appendix C.10	Contents of the PEDRSEC3 . FMT Format File	48

1.0 Introduction

The MOLA Science Team is required to create, validate, and archive the MOLA standard data products. To define each standard data product, the MOLA Science Team is required to provide a Software Interface Specification (SIS). The SIS shall describe the data product contents and define the record and data format. The Planetary Data System's (PDS) Geosciences Node has agreed to archive the MOLA standard data products. The MOLA archive volume shall be described in a separate SIS. The MOLA standard science data products are the Aggregated Experiment Data Record—all MOLA raw data aggregated by orbit; Precision Experiment Data Record—MOLA science data processed into profiles with precision orbit locations added; Any Experiment Gridded Data Record—MOLA gridded data in 2 different densities. This SIS shall define the Precision Experiment Data Record (PEDR) Data Product.

1.1 Purpose

This document describes the format and contents of the PEDR Data Product. This includes a description of the required SFDU format and the record description and contents of the PEDR File.

1.2 Scope

This SIS defines the format of the SFDU labels and headers and the Precision Experiment Data Record down to the bit level. Also, the PEDR Data Product software, hardware, and human interfaces shall be mentioned in order to describe the interface; the actual software, hardware, or human node on the other side of the interface shall be described in detail in its own interface or other reference document.

1.3 Applicable Documents

1. MOLA-672-PL-89.354 *Operations Facility Configuration and Control Plan*, Version 1.0, NASA Goddard Space Flight Center Wallops Flight Facility, January 5, 1990
2. MOLA-972-SP-91.163 *Mars Orbiter Laser Altimeter Aggregated Experiment Data Record Product Software Interface Specification Document*, Version 1.0, NASA Goddard Space Flight Center Wallops Flight Facility, March 31, 1997
3. SFOC-0088-00-07-02 *Space Flight Operations Center User's Guide for Work Station End Users, Volume 2: Working with File Data*, Version 17.0, Draft, Jet Propulsion Laboratory, January 1992
4. MO-642-3-PDB-UG-01 *Mars Observer Project Database (MO PDB) User Overview*, Strawn, Jet Propulsion Laboratory, February 7, 1990
5. MOSO0099-04-00 *Planetary Science Data Dictionary Document*, PDS Version 3.0, Jet Propulsion Laboratory, November 20, 1992, JPL D-7116, Rev C
6. MOLA-972-SP-92-232 *Mars Orbiter Laser Altimeter Any-Experiment Gridded Data Product Software Interface Specification*, Version 1.0, NASA Goddard Space Flight Center Wallops Flight Facility, March 31, 1997
7. MOLA-972-SP-92.213 *MOLA CD-ROM Standard Product Archive Collection Software Interface Specification*, Version 1.0, S. Slavney, R. E. Arvidson, Washington University, August 11, 1993

1.4 Functional Description

1.4.1 Data Content Summary

The PEDR data product contains the along-track, time series collection of the MOLA instrument's science mode data in engineering and physical units. Precision orbit data describing the instrument's position and location has been added to each record. The precision orbit data is supplied by the MOLA Science Team.

Using the precision orbit data, the accuracy of the MOLA footprint is 30 meters radially; 30 meters along track; 30 meters across track.

1.4.2 Source and Transfer Method

The PEDR Data Product is created on the MOLA operations computer system. The PEDR Data Product is created by reading the Aggregated Experiment Data Record (AEDR) Data Product record by record, computing the applicable science parameters (as described in Section 4.0), appending the precision orbit data, and wrapping the whole file with SFDR headers and labels. This SIS will detail the format of the PEDR Data Product. The AEDR Data Product is described in Applicable Document #2. After creation and verification, the PEDR Data Product shall be transferred to the MOLA SOPC to await delivery to the Planetary Data System's (PDS) Geosciences Node where it will be archived to CD-ROM and made available to the science community. The PEDR Data Product shall remain available to the MOLA Science Team on the MOLA operations file system.

1.4.3 Recipients and Utilization

The PEDR data product shall be used to create the Experiment Gridded Data Record (EGDR) data products.

The PDS shall receive the PEDR data product and make it available to the science community.

The PEDR data product shall remain on the MOLA operations file system and be available to the MOLA Science Team for further investigations.

1.4.4 Pertinent Relationships with Other Interfaces

The PEDR data product is created from the Aggregated Experiment Data Record (AEDR) data product. Any changes to the AEDR data product could affect the format or content of the PEDR data product. See Applicable Document #2 for a detailed description of the AEDR Data Product.

Any changes to the PEDR data product, either format or content shall affect the software that creates the data product.

Additionally, any changes to the PEDR data product could affect the EGDR data products' content or format or affect the software that creates the EGDR data products. See Applicable Document #6 for a detailed description of the EGDR Data Products.

1.5 Assumptions and Constraints

The PEDR data product contains only MOLA science mode data.

Each PEDR data product shall encompass one orbit of MOLA data.

2.0 Environment

2.1 Hardware Characteristics and Limitations

Not applicable.

2.2 Interface Medium and Characteristics

The PEDR data product shall be produced on computer(s) within the MOLA operations environment. The PEDR data product shall be transferred to the MOLA SOPC via FTP in preparation for distribution to the PDS Geosciences Node. The SOPC architecture is described in Applicable Document #1. The PEDR data product will be transferred to the PDS Geosciences Node via FTP from the SOPC. The PDS will write the data products to CD-ROMs for distribution to the science community.

2.3 Failure Protection, Detection, and Recovery Features

2.3.1 Backup Requirements

The PEDR data product will be retained on the MOLA operations file system for back up purposes and shall be archived on magnetic media. The PEDR data product is distributed to the PDS for archival. The MGS Project Database will be available as an additional backup location.

2.3.2 Security / Integrity Measures

Refer to Applicable Document #1 for a description of the MOLA *operations* system security and integrity plan.

2.4 End-Of-File (or Medium) Convention

The PEDR data product is a standard UNIX flat file in Standard Formatted Data Unit (SFDU) format. SFDU formatted objects have labels and headers describing the high level structure of the object and the content of the object. The end of the PEDR data product will be detected by the end-of-file marker. In the FORTRAN programming language, fixed-length record files may be opened using the keyword `access='direct'`, `recl=776`, and end-of-file may be detected by the `err=` keyword in the READ statement.

3.0 Access

3.1 Access Tools

The MOLA Science Team shall have the capability to access the PEDR data product on the MOLA operations file system via FTP. The science community will have access to the PEDR Data Product through the Archive Volume produced by the PDS Geosciences Node and should obtain the MOLA CD-ROM Archive Volume SIS, Applicable Document #7 for information on data access. The MOLA Science Team will not provide the PDS any special tools to access the PEDR Data Product.

3.2 Input / Output Protocol

N/A

3.3 Timing and Sequencing Characteristics

A PEDR data product will be created for each orbit containing MOLA science data. Data products will be created as precision orbit data becomes available. The PEDR data product may be re-processed up to three times depending on new releases of precision orbit data. PEDR data products will be created for all the MOLA science data collected during the MGS mapping mission.

3.4 PDB Information

The PEDR Data Product will be stored in the Science category as a science data product in the PDB. See Applicable Document #4 for an end user overview of the PDB.

The data set id for the MOLA PEDR data product is MGS-M-MOLA-3-PEDR-L1A-V1.0. This is the data set id that was provided to the PDB and the Planetary Data System. This id describes the overall PEDR data product. The version number is incremented should the PEDR Data Product format change.

The PDB required keywords are

PDS_VERSION_ID	PRODUCT_RELEASE_DATE
RECORD_TYPE	PRODUCT_VERSION_TYPE
FILE_RECORDS	START_TIME
RECORD_BYTES	STOP_TIME
LABEL_RECORDS	NATIVE_START_TIME
FILE_NAME	NATIVE_STOP_TIME
DATA_SET_ID	SPACECRAFT_CLOCK_START_COUNT
PRODUCT_ID	SPACECRAFT_CLOCK_STOP_COUNT
SPACECRAFT_NAME	PRODUCT_CREATION_TIME
INSTRUMENT_ID	MISSION_PHASE_NAME
INSTRUMENT_NAME	ORBIT_NUMBER
TARGET_NAME	PRODUCER_ID
SOFTWARE_NAME	PRODUCER_FULL_NAME
UPLOAD_ID	PRODUCER_INSTITUTION_NAME
SOURCE_PRODUCT_ID	DESCRIPTION

4.0 Detailed Interface Specifications

4.1 Labeling and Identification

The PEDR Data Product shall be labeled to form an SFDU as described in Section 4.3. The data set id for the PEDR Data Product and required catalog keywords are listed in Section 3.4.

The file naming convention for each PEDR data product produced is AP#####a.B, where:

- A represents the MOLA instrument, an altimeter
- P is the data product, PEDR, identifier
- ##### is the orbit number with leading zeros
- a is the product edition number or letter
- B indicates the file is fixed point, binary.

4.2 Structure and Organization Overview

The PEDR Data Product shall be written as a standard UNIX flat, sequential file with the MOLA data in spacecraft event time-ordered sequence. Each 776-BYTE record contains two seconds of data (a frame) extracted from the science mode telemetry packet. The data records are wrapped with the appropriate SFDU labels and headers, comprising a total of 10 776-byte records. There shall be a primary label, a catalog label and header, and a data label. The catalog label shall have a corresponding end label to delimit the catalog information from the data. See Figure 1 for a representation of the PEDR data product.

4.3 Substructure Definition and Format

The following sections define in detail the label, header, and data formats and content.

4.3.1 Header / Trailer Description Details

An example of the labels and K-header is in Appendix C.

4.3.1.1 Primary SFDU Label

The Primary SFDU Label, also known as the aggregation label or Z-label delimits the entire product. The Primary Label is 20 bytes long and shall have the following format for the PEDR data product.

```
CCSD3ZF0000100000001
```

where:

- CCSD is the Control Authority ID
- 3 is the SFDU version ID
- Z is the class ID for primary labels
- F is the SFDU delimiter type, total EOFs.
- 0 is a spare octet
- 0001 is the Data Descriptive Package ID (DDPID)
- 0000001 is the delimiter value for this label; indicates the number of EOFs delimiting the product.

4.3.1.2 Catalog Label and Header

The catalog labels and header, also known as the K-header, are made up of the start and end labels and the catalog data objects that are to be stored in the Mars Global Surveyor PDB and the Plane-

tary Data System's data base. The start label has the following form:

```
NJPL3KS0PDSX$$INFO$$
```

where:

NJPL is the Control Authority ID
 3 is the SFDU version ID
 K is the class ID for catalog data object labels
 S is the SFDU delimiter type, start marker.
 0 is a spare octet
 PDSX is the Data Descriptive Package ID
 \$\$INFO\$\$ is the delimiter value for this label

After the label, shall be the catalog entries required by the Project. These shall be in the KEY=WORD=VALUE format. Each KEYWORD=VALUE string shall be terminated by a carriage return, line feed combination. The required keywords are listed in Section 3.4. The catalog entries (keywords) with example values are listed in Appendix C.1. Applicable Document #5 contains definitions of the keywords listed in the appendix.

Planetary Data System required object definitions and pointers are contained in the catalog header. Each data parameter in the product is defined by the object structure; the pointers direct the user to format files which fully define the PEDR record format and contents. Appendix C contains an example of the object definitions and pointers.

The catalog entries will be delimited by the K-header end label; it has the following form:

```
CCSD$$MARKER$$INFO$$
```

4.3.1.3 Data Label

The data or I-class Label precedes the actual data in the SFDU. This label is also known as the data object label or the tertiary header. The I-class label is registered individually with the JPL Control Authority and bears a unique DDPID. The start label has the following format

```
NJPL3IF0004100000001
```

where:

NJPL is the Control Authority ID
 3 is the SFDU version ID
 I is the class ID for data labels
 F is the SFDU delimiter type, Total EOFs
 0 is a spare octet
 0041 is the Data Descriptive Package ID
 00000001 is the delimiter value for this label; indicates the number of EOFs delimiting the product.

4.3.2 Data Description Details

A Precision Experiment Data Record contains MOLA science mode telemetry data that has been converted to engineering and physical units. Each PEDR contains a 2 second span of data, called a frame, that is retrieved from the 14 second MOLA science mode telemetry packet. Therefore, seven PEDRs are generated from each MOLA science mode telemetry packet. In addition to the frame data, the packet's engineering and housekeeping data are retained and subcommutated

among the seven PEDRs that comprise a packet. Additional packet information, *e.g.*, packet header, are stored in the PEDR as well as data correction values which were used to process the telemetry data into the PEDR data. Storing the data correction values ensures that the telemetry data can be re-created from the PEDR data.

Contained in a PEDR are the range value computed at the frame mid-point, the planetary radius at the frame mid-point, and the planetary radius for each shot. There are 20 possible shots in a 2 second frame. Additionally, location, *i.e.*, latitude, longitude, and radial distance, obtained from the precision orbit data, is stored in the PEDR. The precision orbit data is gathered at the frame mid-point with respect to the Mars Global Surveyor center of mass. The range and planetary radius values are computed with respect to the center of mass of the Mars Global Surveyor. Additional information describing the instrument and its configuration are included in the PEDR.

A complete listing of all parameters contained in a PEDR can be found in Table 1. A description of the parameters contained in a PEDR is found in Table 2. The engineering/housekeeping data are listed in Table 3; this table also describes the location of the engineering/housekeeping data among the seven PEDRs that constitute a MOLA telemetry packet. Additionally, the PEDR format and contents are described in the PEDR Data Dictionary in Appendix B.

4.4 Volume, Size, and Frequency Estimates

The size of each PEDR data product shall vary depending in the number of science mode packets produced during an orbit. The maximum number of science mode packets that could be produced during an orbit is approximately 486, therefore the maximum number of PEDRs in a PEDR Data Product would be approximately 3402. Each PEDR shall contain 776 bytes.

The PEDR data product will be produced as the AEDR files and corresponding precision orbit data become available. The data products will be produced during a standard 5 day / 40 hour work week.

Approximately 13 PEDR Data Products shall be produced for each mapping mission day resulting in a daily volume of 34 Mbytes. During the period of time designated as contingency science or phasing orbits, MOLA ranges to the surface for only 20-30 minutes and the volume is accordingly reduced.

FIGURES




Figure 1: PEDR Data Product Structure and Organization

TABLES

Table 1: PEDR Data Product Record Format

Start Byte	Parameter	Bytes	Units	End Byte
1	frame mid-point time whole seconds (Elapsed Time from J2000)	4	seconds	4
5	frame mid-point time fractional seconds (Elapsed Time from J2000)	4	microseconds	8
9	orbit reference number	4	counts	12
13	frame mid-point areocentric latitude of spacecraft	4	degrees * 10^6	16
17	frame mid-point areocentric longitude of spacecraft	4	degrees * 10^6	20
21	frame mid-point radial distance of spacecraft	4	centimeters	24
25	frame mid-point range	4	centimeters	28
29	shot quality flag	4		32
33	shot quality descriptor flag	16		48
49	shot planetary radius (20 * 4)	80	centimeters	128
129	frame mid-point planetary radius	4	centimeters	132
133	instrument attitude right ascension	4	milliradians	136
137	instrument attitude declination	4	milliradians	140
141	instrument attitude twist	4	milliradians	144
145	corrected received pulse energy (20 * 2)	40	attojoules	184
185	surface reflectivity * atmospheric transmittance	40	parts in 10^5	224
225	trigger channel number (20 * 1)	20		244
245	returned pulse width at threshold	40	nanoseconds * 10	284
285	received optical pulse width (20 * 2)	40	nanoseconds * 10	324
325	parallax delta-latitude	4	degrees * 10^9m^{-1}	328
329	parallax delta-longitude	4	degrees * 10^9m^{-1}	332
333	crossover residual	4	centimeters	336
337	frame mid-point latitude and longitude	8	degrees * 10^6	344
345	laser transmit power (20 * 2)	40	mJ * 100	384
385	shot classification code	40		424
425	channel background noise (8 * 4)(per half-frame and channel)	32	counts	456
457	range delay	4	centimeters	460
461	range width	4	centimeters	464
465	receiver channel threshold (8 * 2)(per half-frame and channel)	16	millivolts	480
481	receiver channel mask	2		482
483	algorithm word (MIN_HITS)	2		484
485	algorithm word (HIT_COUNT)	2	counts	486
487	frame counter	2		488

Table 1: PEDR Data Product Record Format (Continued)

Start Byte	Parameter	Bytes	Units	End Byte
489	trigger channel	2		490
491	within-packet frame index	2	(1-7)	492
493	packet source header	8		500
501	telemetry packet coarse time code - seconds (J2000 elapsed time)	4	seconds	504
505	telemetry packet coarse time code - milliseconds	2	ms	506
507	telemetry packet fine time code	2	counts	508
509	engineering / housekeeping data	28		536
537	Orbit quality flag	2		538
539	Attitude flag	2		540
541	Frame local time	2	radians * 10 ⁴	542
543	Phase angle	2	radians * 10 ⁴	544
545	Solar incidence angle	2	radians * 10 ⁴	546
547	Emission angle	2	radians * 10 ⁴	548
549	Atmospheric opacity (Tau)	4	pure number * 10 ⁶	552
553	Double precision frame mid-point time in IEEE standard (Elapsed time from J2000)	8	seconds	560
561	trigger channel raw received pulse energy (20 * 1)	20	counts (0-255)	580
581	trigger channel raw received pulse width (20 * 1)	20	counts (0-63)	600
601	delta spacecraft latitude	4	degrees * 10 ⁶	604
605	delta spacecraft longitude	4	degrees * 10 ⁶	608
609	delta spacecraft radial distance	4	centimeters	612
613	Areoid radius	4	centimeters	616
617	Off-nadir angle	4	degrees * 10 ⁶	620
621	Encoder bits	20	counts	640
641	delta areoid	4	cm	644
645	MOLA clock rate	4	Hz	648
649	MOLA range value (20 * 4)	80	centimeters	688
729	range correction (20 * 2)	40	centimeters	768
769	delta latitude	4	degrees * 10 ⁶	772
773	delta longitude	4	degrees * 10 ⁶	776
		776	bytes total	

Table 2: MOLA Precision Experiment Data Record (PEDR) Contents
Rate: 1 every 2 seconds

Parameter	Bytes	Units	Description
- frame mid-point time whole seconds	4	Seconds	The whole portion of the Elapsed Time since J2000 at the frame mid-point ^a in the MOLA data frame
- frame mid-point time fractional seconds	4	Microseconds	The fractional portion of the Elapsed Time since J2000 at the frame mid-point ^a in the MOLA data frame
- orbit reference number	4	Counts	Mapping mission orbit number determined by Mars Global Surveyor flight operations system at frame mid-point
- frame mid-point areocentric latitude of spacecraft	4	Degrees * 10 ⁶	MGS Spacecraft areocentric latitude, in IAU1991 coordinates, associated with MOLA data frame mid-point; from Precision Orbit data
- frame mid-point areocentric longitude	4	Degrees * 10 ⁶	MGS Spacecraft east longitude, in IAU1991 coordinates, associated with MOLA data frame mid-point; from Precision Orbit data
- frame mid-point radial distance of spacecraft	4	Centimeters	Radial distance (<i>i.e.</i> , the distance from Martian body-center to Mars Global Surveyor spacecraft center of mass) associated with MOLA data frame mid-point; from Precision Orbit data
- frame mid-point range	4	Centimeters	MOLA range (corrected to Mars Global Surveyor center of mass) associated with MOLA data frame mid-point, obtained from a straight line best-fit of the individual (up to 20) MOLA range measurements in the MOLA data frame
- shot quality flag	4		3 bytes—flag whether good/bad shot (20 least significant bits, one for each of the 20 shots, with least significant bit, 0, being shot 1 and bit 19 being shot 20) and each bit set to 0 for good, 1 for bad shot; bits 20–23 are unused 1 byte—good shot counter, (total of bits set to 0 in above 20 bits)
- shot quality descriptor flag	16		Flag indicating whether the packet or individual shots passed or failed the various shot quality tests. Reading the flag from right to left with the rightmost bit being bit 0 and the leftmost bit being bit 127 the format of the flag is bit 0: packet validity checksum test bit 1: computer software checksum test bit 2: frame acquisition vs. tracking mode test bit 3: first shot is an OTS shot test bits 4–23: transmit power test bits 24–43: non-zero 1st channel test bits 44–63: return energy test bits 64–83: range window test bits 84–103: range comparison test bits 104–127: unused

Table 2: MOLA Precision Experiment Data Record (PEDR) Contents (Continued)
Rate: 1 every 2 seconds

Parameter	Bytes	Units	Description
- shot quality descriptor flag (contd.)			A 1 indicates the test was failed, 0 indicates the test was passed. For the bits that flag each shot the lower bit corresponds to shot 1 and the higher bit corresponds to shot 20.
- shot planetary radius	80	Centimeters	Array of 20 MOLA planetary radii, one per shot, in the data frame; the distance from the center of Mars to the point on the surface of Mars described by the MOLA range, 20 4-byte values
- frame mid-point planetary radius	4	Centimeters	Planetary radius associated with MOLA data frame mid-point; the distance from the center of Mars to the point on the surface of Mars described by the MOLA mid-point range
- instrument attitude right ascension	4	Milliradians	MOLA right ascension at data frame mid-point
- instrument attitude declination	4	Milliradians	MOLA declination at data frame mid-point
- instrument attitude twist	4	Milliradians	MOLA twist at data frame mid-point
- corrected received pulse energy	40	Attojoules	Corrected surface-scattered return energy as measured by the pulse width and area counters, corrected for threshold setting, 20 2-byte values
- surface reflectivity * atmospheric transmittance	40	Pure fraction * 10^5	Relative Martian surface reflectivity values, one per shot; 20 2-byte values
- trigger channel number	20		Channel number of first MOLA filter channel to trigger, 20 1-byte values
- returned pulse width at threshold	40	Nanoseconds * 10	Time between threshold crossings of the detected pulse. The pulse width is used to correct the time-of-flight to the optical pulse centroid, but <code>rcv_pulse_energy_counts</code> may be saturated. In this case, the timing correction is limited to the equivalent of a six-degree slope. 20 2-byte values
- received optical pulse width	40	Nanoseconds * 10	Received optical pulse width, corrected for filter characteristics and threshold settings, as determined by the receiver model (one sigma value, with the minimum limited by the filter response). The pulse width provides an estimate of target slope and/or roughness, assuming nadir-looking geometry
parallax delta-latitude	4	degrees * 10^9m^{-1}	change in latitude with respect to planetary radius at frame midpoint due to parallax
parallax delta-longitude	4	degrees * 10^9m^{-1}	change in longitude with respect to planetary radius at frame midpoint due to parallax
crossover residual	4	Centimeters	Crossover residual of planetary radius with respect to MOLA database at frame midpoint

Table 2: MOLA Precision Experiment Data Record (PEDR) Contents (Continued)
Rate: 1 every 2 seconds

Parameter	Bytes	Units	Description
- frame mid-point latitude, longitude	8	Degrees * 106	The areocentric latitude and the East longitude, in IAU1991 coordinates, of the intersection point between the frame mid-point shot and the Mars surface; from Precision Orbit data; 2 4-byte values
- laser transmit power	40	mJ * 100	MOLA laser transmitted pulse energy, corrected for detector and heat sink temperatures, 20 2-byte values
- shot classification code	40		shot classification and weighting codes: 0 denotes a false return or no trigger; 1 denotes a ground return.
- channel background noise counts	32	Counts	Frame value for background levels in the MOLA channels, at half-frame rate (order: 1A, 2A, 3A, 4A, 1B, 2B, 3B, and 4B where A is first half and B is second half of data frame), for raw background counts (prior to engineering unit conversion) equal to or less than 23 the converted value is set to 1.0, 8 4-byte values
- range delay	4	Centimeters	Frame value of range gate delay (to beginning of range window)
- range width	4	Centimeters	Frame value of range gate width
- receiver channel threshold settings	16	Millivolts	Threshold settings for the 4 MOLA channels, at half-frame rate (order: 1A, 2A, 3A, 4A, 1B, 2B, 3B, and 4B), 8 2-byte values
- receiver channel mask	2		MOLA channel mask setting for the frame; the mask indicates whether any of the 4 channels have been commanded off
- algorithm word MIN_HITS	2		Frame value for the flight software word MIN_HITS
- algorithm word HIT_COUNT	2	Counts	Frame value for the flight software word HIT_COUNT
- frame counter	2		Software status value
- trigger channel	2		Software status value
- within-packet frame index	2	Count	Frame number (among seven frames in MOLA telemetry packet) generated in Ground Data System processing
- packet source header	8		Information placed in MOLA telemetry packet by Payload Data System
- telemetry packet coarse time code seconds	4	ET (Elapsed Time) seconds	The whole portion of the Payload Data System generated time code in ET seconds referenced to J2000; a signed number.
- telemetry packet coarse time code milliseconds	2	ET milliseconds	The fractional portion of the Payload Data System generated time code in ET seconds referenced to J2000; a signed number
- telemetry packet fine time code	2	counts	MOLA generated fine time counter

Table 2: MOLA Precision Experiment Data Record (PEDR) Contents (Continued)
Rate: 1 every 2 seconds

Parameter	Bytes	Units	Description
- engineering/ house-keeping data	28		Complete set of packet engineering and housekeeping data (196 bytes) from each MOLA telemetry packet, subcommutated into 7 data frames, 28 bytes appear at this location in each frame
- orbit quality flag	2		Flag indicating origin of orbit. 0 indicates JPL NAV team was producer; 1 or higher indicates the MOLA Science Investigation Team.
- attitude flag	2		Flag to indicate spacecraft attitude information was missing for this frame. Set to 2 if attitude information was missing for part of the frame; 3 if missing for entire frame.
- frame local time	2	radians * 104	The subsolar longitude on Mars, -Pi to Pi.
- phase angle	2	radians * 104	The angle between the vectors from Mars to Mars Global Surveyor and from Mars to the Sun at the frame mid-point location
- solar incidence angle	2	radians * 104	The angle between the Mars surface normal vector and the Sun vector at the frame mid-point location
- emission angle	2	radians * 104	The angle between the Mars surface normal vector and the Mars Global Surveyor vector at the frame mid-point location
- Atmospheric opacity	4	Pure number * 10 ⁶	May be retrieved from TES data; nominally 0.5
- double precision frame mid-point time	8	seconds	The frame mid-point time represented in IEEE standard double precision; ET seconds from J2000
- trigger channel raw received pulse energy	20	Counts	The received pulse energy counts; 255=>saturation; 20 1-byte values
- trigger channel raw received pulse width	20	Counts	The received pulse width counts; 63=>saturation; 20 1-byte values
delta spacecraft latitude	4	Degrees * 106	The average change in spacecraft areocentric latitude associated with each 20-shot MOLA frame
delta spacecraft longitude	4	Degrees * 106	The average change in spacecraft areocentric longitude associated with each 20-shot MOLA frame
delta spacecraft radius	4	Centimeters	The average change in spacecraft areocentric radius associated with each 20-shot MOLA frame
- Areoid radius	4	Centimeters	The radius of the reference areoid with 3396 kilometer mean equatorial radius, determined from the GMM-1 or more recent potential model of degree and order 70
- Off-nadir angle	4	Degrees * 106	Angle between the transmitted laser shot direction and areocentric direction, at spacecraft frame mid-point
- Encoder bits	20		The start and stop encoder bits for each MOLA shot. With these bits, the MOLA shot range is interpolated within each clock count. The start and stop encoders are stored in bits 0-1 and 4-5 of each byte

Table 2: MOLA Precision Experiment Data Record (PEDR) Contents (Continued)
Rate: 1 every 2 seconds

Parameter	Bytes	Units	Description
- delta areoid	4	centimeters	The average change in areoid associated with each 20-shot MOLA frame.
- MOLA clock rate	4	Hertz	The MOLA clock frequency used to calculate laser pulse time-of-flight.
- MOLA range	80	centimeters	The MOLA one-way range value per shot; the raw MOLA time-of-flight range plus the range correction below, 20 4-byte values
- range correction	40	centimeters	Correction to the range value due to the detector response and range walk, 20 2-byte values
- delta latitude	4	Degrees * 10 ⁶	The average distance between each areocentric latitude associated with each 20-shot MOLA frame
- delta longitude	4	Degrees * 10 ⁶	The average distance between each areocentric longitude associated with each 20-shot MOLA frame
TOTAL:	776		

- a. The phrase “frame mid-point” is used to denote the transmit time of shot 10.5, a point midway between the 10th and 11th shots in the set of 20 laser shots in a MOLA frame.

Table 3: PEDR Data Product Subcommutated Data Format

Packet Byte	Contents	Length in Bytes	Frame	Frame Start Byte	Frame Stop Byte
12	Computer Memory temperature	2	PEDR 1	509	510
13	Computer CPU temperature	2	PEDR 1	511	512
14	Power Supply temperature	2	PEDR 1	513	514
15	Computer I/O temperature	2	PEDR 1	515	516
16	LASER array sink heat temperature	2	PEDR 1	517	518
17	LASER diode array drive electronics temperature	2	PEDR 1	519	520
18	Optical Test Source (OTS) LED temperature	2	PEDR 1	521	522
19	100 MHz Oscillator temperature	2	PEDR 1	523	524
20	Start Detector temperature	2	PEDR 1	525	526
21	Outside Detector box temperature	2	PEDR 1	527	528
22	LASER Radiator Opposite Output port temperature	2	PEDR 1	529	530
23	LASER Radiator Output port temperature	2	PEDR 1	531	532
24	Interface Plate near "hot foot" temperature	2	PEDR 1	533	534
25	Radiation shield transition temperature	2	PEDR 1	535	536
26	Electronics Box top near S/C thermistor temperature	2	PEDR 2	509	510
27	LASER box near "hot foot" temperature	2	PEDR 2	511	512
28	28 Volt monitor	2	PEDR 2	513	514
29	Reference Voltage monitor	2	PEDR 2	515	516
30	+12 Volt voltage monitor	2	PEDR 2	517	518
31	24 Volt voltage monitor	2	PEDR 2	519	520
32	+5 Volt voltage monitor	2	PEDR 2	521	522
33	-12 Volt voltage monitor	2	PEDR 2	523	524
34	LASER / thermal current monitor	2	PEDR 2	525	526
35	-5 Volt voltage monitor	2	PEDR 2	527	528
36	Power Supply current monitor	2	PEDR 2	529	530
37	High Voltage current monitor	2	PEDR 2	531	532
38	-12 Volt current monitor	2	PEDR 2	533	534
39	+12 Volt current monitor	2	PEDR 2	535	536
40	-5 Volt current monitor	2	PEDR 3	509	510
41	+5 Volt current monitor	2	PEDR 3	511	512
42	Current STATUS register value (SEU counter)	1	PEDR 3	513	513
43	Software Version Number Upper (4.4 bit format)	1	PEDR 3	514	514
43	Software Version Number Lower (4.4 bit format)	1	PEDR 3	515	515
55	Range Tracking Status (frame #7654321) "(1= tracking, 0 = acquisition) (MSB=OTS)"	1	PEDR 3	516	516
44	Flag word (2 KB RAM block test)	2	PEDR 3	517	518

Table 3: PEDR Data Product Subcommutated Data Format (Continued)

Packet Byte	Contents	Length in Bytes	Frame	Frame Start Byte	Frame Stop Byte
46	Status Flags (SFLAG1 (16 bits), SFLAG2 (16 bits))	4	PEDR 3	519	522
50	Software validity checksum	2	PEDR 3	523	524
52	Received command count (modulo 8 bits)	1	PEDR 3	525	525
53	Command error count (modulo 8 bits)	1	PEDR 3	526	526
54	Transmitter threshold setting (XMITDA)	2	PEDR 3	527	528
56	Range gate tracker array (73.728 km)	8	PEDR 3	529	536
64	Range gate tracker array (cont.)	28	PEDR 4	509	536
92	Range gate tracker array (cont.)	12	PEDR 5	509	520
104	HSTART value for HISTOGRAM dump	4	PEDR 5	521	524
	unused	4	PEDR 5	525	528
106	Valid commands received count (modulo 16 bits)	2	PEDR 5	529	530
108	Memory dump segment (16 Kbytes/16 bytes = 1024 packets ~ 4 hours)	6	PEDR 5	531	536
114	Memory dump segment (cont.)	10	PEDR 6	509	518
124	Command echo	16	PEDR 6	519	534
140	Packet validity checksum	2	PEDR 6	535	536
142	OTS Range	4	PEDR 7	509	512
144	OTS 1st channel received energy	4	PEDR 7	513	516
145	Spare	4	PEDR 7	517	520
223	OTS transmit power	4	PEDR 7	521	524
3	OTS pulse width	1	PEDR 7	525	525
3	OTS pulse amplitude	1	PEDR 7	526	526
	OTS quality flag	1	PEDR 7	527	527
11	Packet Type (0 for Science Mode)	1	PEDR 7	528	528
	Areocentric longitude of the Sun	2	PEDR 7	529	530
	unused	6	PEDR 7	531	536
325	frame mid-point coordinates (x,y,z)	12	centimeters		336
325	frame mid-point coordinates (x,y,z)	12	centimeters		336
325	frame mid-point coordinates (x,y,z)	12	centimeters		336
325	frame mid-point coordinates (x,y,z)	12	centimeters		336

APPENDICES

Appendix A Acronyms

AEDR	Aggregated Experiment Data Record
aJ	attoJoule
DDPID	Data Descriptive Package ID
EGDR	Experiment Gridded Data Record
ET	Elapsed Time
EUC	Engineering Unit Conversion
FTP	File Transfer Protocol
Gbytes	gigabytes
GMM-1	Goddard Mars Model-1 potential model (Smith et al., 1993)
GSFC	Goddard Space Flight Center
IAU1991	Report of the IAU/IAG/COSPAR Working Group on Cartographic Coordinates and Rotational Elements of the Planets and Satellites, Buenos Aires, 1991.
JPL	Jet Propulsion Laboratory
MGS	Mars Global Surveyor
Mbytes	megabytes
mJ	milliJoule
MOLA	Mars Orbiter Laser Altimeter
ms	milliseconds
NAIF/ SPICE	Navigation Ancillary Information Facility / Spacecraft Ephemeris, Planet Ephemeris, Instrument Offset, Instrument Inertial Orientation (C), Event Oriented Information Kernels
OTS	Optical Test Source
PEDR	Precision Experiment Data Record
PDB	Project Data Base
PDS	Planetary Data System
SFDU	Standard Formatted Data Unit
SFOC	Space Flight Operations Center
SIS	Software Interface Specification
SOPC	Science Operations Planning Computer
SPICE	Spacecraft Ephemeris, Planet Ephemeris, Instrument Offset, Instrument Inertial Orientation (C), Event Oriented Information Kernels
TBD	to be determined
WFF	Wallops Flight Facility

Appendix B Precision Experiment Data Record Catalog Files

This version of the MOLAPEDR SIS contains no listing of PDS Catalog Files

Appendix C PEDR Data Product SFDU Labels and Format Files

C.1 PEDR Data Product SFDU Labels and Catalog Header

```

CCSD3ZF0000100000001NJPL3KS0PDSX$$INFO$$
PDS_VERSION_ID          = PDS3
RECORD_TYPE             = FIXED_LENGTH
FILE_RECORDS           = 'UNK'
RECORD_BYTES           = 776
LABEL_RECORDS          = 10
FILE_NAME               = 'AP00003K.B'
^PEDR_FR_1_TABLE       = 11
^PEDR_FR_2_TABLE       = 11
^PEDR_FR_3_TABLE       = 11
^PEDR_FR_4_TABLE       = 11
^PEDR_FR_5_TABLE       = 11
^PEDR_FR_6_TABLE       = 11
^PEDR_FR_7_TABLE       = 11
DATA_SET_ID            = 'MGS-M-MOLA-3-PEDR-L1A-V1.0'
PRODUCT_ID             = 'MOLA-AP00003K.B'
SPACECRAFT_NAME        = 'MARS_GLOBAL_SURVEYOR'
INSTRUMENT_ID          = 'MOLA'
INSTRUMENT_NAME        = 'MARS_ORBITER_LASER_ALTIMETER'
TARGET_NAME            = 'MARS'
SOFTWARE_NAME          = 'PREC_PP_7.00'
UPLOAD_ID              = 'SM-7.6'
SOURCE_PRODUCT_ID      = {"MOLA-AA00003F.B", "MOLA-APPLCT01.T",
  "", "", "", "", "", ""}
PRODUCT_RELEASE_DATE   = 1998-141
START_TIME             = 1997-212T19:10:00.000
STOP_TIME              = 1997-212T19:45:00.000
NATIVE_START_TIME     = -76351736.816730
NATIVE_STOP_TIME      = -76349636.816730
SPACECRAFT_CLOCK_START_COUNT = 443588190.140
SPACECRAFT_CLOCK_STOP_COUNT = 443595246.140
PRODUCT_CREATION_TIME = 1998-051T17:42:37.881
MISSION_PHASE_NAME    = 'ORBIT INSERTION'
ORBIT_NUMBER          = 00003
PRODUCT_VERSION_TYPE  = {"R007-CALIBRATED REL.", "O00003 - ORBIT 3",
  "P007-CALIBRATED REL.", "E007-CALIBRATED REL."}
PRODUCER_ID           = 'MGS_MOLA_TEAM'
PRODUCER_FULL_NAME    = 'DAVID E. SMITH'
PRODUCER_INSTITUTION_NAME = 'GODDARD SPACE FLIGHT CENTER'
DESCRIPTION            = "The PEDR data product contains the along-track,
  time series collection of MOLA instrument, science mode data in
  engineering and physical units. Precision orbit data describing the
  instrument's position and location has been added to each record. The
  precision data is supplied by the MOLA Science Team."

OBJECT                = PEDR_FR_1_TABLE
INTERCHANGE_FORMAT    = BINARY
ROWS                  = 'UNK'

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

COLUMNS                = 73
ROW_BYTES               = 776
^FIRST_STRUCTURE        = 'PEDRSEC1.FMT'
^FR_1_ENG_STRUCTURE     = 'PEDRENG1.FMT'
^THIRD_STRUCTURE        = 'PEDRSEC3.FMT'
DESCRIPTION              = "This is one of seven table definitions that apply
to the seven possible PEDR record structures, one for each frame. In
each data record, byte 492 (counting from one) identifies the frame
number for the record. This table structure incorporates the
engineering information returned in Frame 1. The 'first_structure'
format file includes descriptions of the first 500 bytes of the record,
'fr_1_eng_structure' format file describes bytes 501 to 528, and the
'third_structure' format file describes bytes 529 to 776."
END_OBJECT              = PEDR_FR_1_TABLE

OBJECT                  = PEDR_FR_2_TABLE
INTERCHANGE_FORMAT      = BINARY
ROWS                    = 'UNK'
COLUMNS                = 73
ROW_BYTES               = 776
^FIRST_STRUCTURE        = 'PEDRSEC1.FMT'
^FR_2_ENG_STRUCTURE     = 'PEDRENG2.FMT'
^THIRD_STRUCTURE        = 'PEDRSEC3.FMT'
DESCRIPTION              = "This is one of seven table definitions that apply
to the seven possible PEDR record structures, one for each frame. In
each data record, byte 492 (counting from one) identifies the frame
number for the record. This table structure incorporates the
engineering information returned in Frame 2. The 'first_structure'
format file includes descriptions of the first 500 bytes of the record,
'fr_2_eng_structure' format file describes bytes 501 to 528, and the
'third_structure' format file describes bytes 529 to 776."
END_OBJECT              = PEDR_FR_2_TABLE

OBJECT                  = PEDR_FR_3_TABLE
INTERCHANGE_FORMAT      = BINARY
ROWS                    = 'UNK'
COLUMNS                = 72
ROW_BYTES               = 776
^FIRST_STRUCTURE        = 'PEDRSEC1.FMT'
^FR_3_ENG_STRUCTURE     = 'PEDRENG3.FMT'
^THIRD_STRUCTURE        = 'PEDRSEC3.FMT'
DESCRIPTION              = "This is one of seven table definitions that apply
to the seven possible PEDR record structures, one for each frame. In
each data record, byte 492 (counting from one) identifies the frame
number for the record. This table structure incorporates the
engineering information returned in Frame 3. The 'first_structure'
format file includes descriptions of the first 500 bytes of the record,
'fr_3_eng_structure' format file describes bytes 501 to 528, and the
'third_structure' format file describes bytes 529 to 776."
END_OBJECT              = PEDR_FR_3_TABLE

OBJECT                  = PEDR_FR_4_TABLE
INTERCHANGE_FORMAT      = BINARY
ROWS                    = 'UNK'

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

COLUMNS                = 60
ROW_BYTES               = 776
^FIRST_STRUCTURE        = 'PEDRSEC1.FMT'
^FR_4_ENG_STRUCTURE     = 'PEDRENG4.FMT'
^THIRD_STRUCTURE        = 'PEDRSEC3.FMT'
DESCRIPTION              = "This is one of seven table definitions that apply
to the seven possible PEDR record structures, one for each frame. In
each data record, byte 492 (counting from one) identifies the frame
number for the record. This table structure incorporates the
engineering information returned in Frame 4. The 'first_structure'
format file includes descriptions of the first 500 bytes of the record,
'fr_4_eng_structure' format file describes bytes 501 to 528, and the
'third_structure' format file describes bytes 529 to 776."
END_OBJECT              = PEDR_FR_4_TABLE

OBJECT                  = PEDR_FR_5_TABLE
INTERCHANGE_FORMAT      = BINARY
ROWS                    = 'UNK'
COLUMNS                = 64
ROW_BYTES               = 776
^FIRST_STRUCTURE        = 'PEDRSEC1.FMT'
^FR_5_ENG_STRUCTURE     = 'PEDRENG5.FMT'
^THIRD_STRUCTURE        = 'PEDRSEC3.FMT'
DESCRIPTION              = "This is one of seven table definitions that apply
to the seven possible PEDR record structures, one for each frame. In
each data record, byte 492 (counting from one) identifies the frame
number for the record. This table structure incorporates the
engineering information returned in Frame 5. The 'first_structure'
format file includes descriptions of the first 500 bytes of the record,
'fr_5_eng_structure' format file describes bytes 501 to 528, and the
'third_structure' format file describes bytes 529 to 776."
END_OBJECT              = PEDR_FR_5_TABLE

OBJECT                  = PEDR_FR_6_TABLE
INTERCHANGE_FORMAT      = BINARY
ROWS                    = 'UNK'
COLUMNS                = 62
ROW_BYTES               = 776
^FIRST_STRUCTURE        = 'PEDRSEC1.FMT'
^FR_6_ENG_STRUCTURE     = 'PEDRENG6.FMT'
^THIRD_STRUCTURE        = 'PEDRSEC3.FMT'
DESCRIPTION              = "This is one of seven table definitions that apply
to the seven possible PEDR record structures, one for each frame. In
each data record, byte 492 (counting from one) identifies the frame
number for the record. This table structure incorporates the
engineering information returned in Frame 6. The 'first_structure'
format file includes descriptions of the first 500 bytes of the record,
'fr_6_eng_structure' format file describes bytes 501 to 528, and the
'third_structure' format file describes bytes 529 to 776."
END_OBJECT              = PEDR_FR_6_TABLE

OBJECT                  = PEDR_FR_7_TABLE
INTERCHANGE_FORMAT      = BINARY
ROWS                    = 'UNK'

```

```

COLUMNS                = 68
ROW_BYTES               = 776
^FIRST_STRUCTURE       = 'PEDRSEC1.FMT'
^FR_7_ENG_STRUCTURE   = 'PEDRENG7.FMT'
^THIRD_STRUCTURE       = 'PEDRSEC3.FMT'
DESCRIPTION            = "This is one of seven table definitions that apply
to the seven possible PEDR record structures, one for each frame. In
each data record, byte 492 (counting from one) identifies the frame
number for the record. This table structure incorporates the
engineering information returned in Frame 7. The 'first_structure'
format file includes descriptions of the first 500 bytes of the record,
'fr_7_eng_structure' format file describes bytes 501 to 528, and the
'third_structure' format file describes bytes 529 to 776."
END_OBJECT             = PEDR_FR_7_TABLE

END

```

C.2 Contents of the MOLA PEDRSEC1.FMT Format File

```

OBJECT                 = COLUMN
NAME                  = FRAME_TIME_WHOLE_SECONDS
DATA_TYPE            = MSB_INTEGER
START_BYTE          = 1
BYTES               = 4
UNIT                = 'SECONDS'
DESCRIPTION         = "Frame mid-point time whole seconds. The integer
represents the whole portion of the Ephemeris Time (in number of seconds)
past J2000."
END_OBJECT          = COLUMN

OBJECT                 = COLUMN
NAME                  = FRAME_TIME_FRAC_SECONDS
DATA_TYPE            = MSB_INTEGER
START_BYTE          = 5
BYTES               = 4
UNIT                = 'MICROSECONDS'
DESCRIPTION         = "The frame mid-point time fractional seconds,
scaled to microseconds. The integer represents the fractional portion
of the Ephemeris Time (in number of microseconds) past J2000."
END_OBJECT          = COLUMN

OBJECT                 = COLUMN
NAME                  = ORBIT_NUMBER
DATA_TYPE            = MSB_UNSIGNED_INTEGER
START_BYTE          = 9
BYTES               = 4
DESCRIPTION         = "Mapping mission orbit number, determined by Mars
Global Surveyor flight operations system."
END_OBJECT          = COLUMN

OBJECT                 = COLUMN

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

NAME = AREOCENTRIC_LATITUDE
 DATA_TYPE = MSB_INTEGER
 START_BYTE = 13
 BYTES = 4
 UNIT = 'DEGREES * (10**6)'
 DESCRIPTION = "The areocentric latitude, IAU1991, of the MOLA data frame mid-point of the Mars Global Surveyor spacecraft center of mass. Obtained from the MOLA Science Investigation Team precision orbit data."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = AREOCENTRIC_LONGITUDE
 DATA_TYPE = MSB_INTEGER
 START_BYTE = 17
 BYTES = 4
 UNIT = 'DEGREES * (10**6)'
 DESCRIPTION = "The East longitude, IAU1991, of the MOLA data frame mid-point of the Mars Global Surveyor spacecraft center of mass. Obtained from the MOLA Science Investigation Team precision orbit data."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = RADIAL_DISTANCE
 DATA_TYPE = MSB_UNSIGNED_INTEGER
 START_BYTE = 21
 BYTES = 4
 UNIT = 'CENTIMETERS'
 DESCRIPTION = "The distance from the Mars body center to the Mars Global Surveyor spacecraft center of mass associated with the MOLA frame mid-point, based on a coordinate system with origin at the center of mass of Mars. Obtained from the MOLA Science Investigation Team precision orbit data."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = FRAME_MID_POINT_RANGE
 DATA_TYPE = MSB_UNSIGNED_INTEGER
 START_BYTE = 25
 BYTES = 4
 UNIT = 'CENTIMETERS'
 DESCRIPTION = "MOLA range (corrected to Mars Global Surveyor center of mass) associated with MOLA data frame mid-point, obtained from a straight line best fitted to the individual MOLA range measurements (up to 20) in the MOLA data frame."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = SHOT_QUALITY_FLAG
 DATA_TYPE = MSB_UNSIGNED_INTEGER
 START_BYTE = 29

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

BYTES = 4
 DESCRIPTION = "3 bytes - flag whether good/bad shot (20 least significant bits, one for each of the 20 shots, with least significant bit, 0, being shot 20) and each bit set to 1 for good, 0 for bad shot. 1 byte - good shot counter, (total of bits set to 1 in above 20 bits)."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = SHOT_QUALITY_DESCRIPTOR_FLAG
 DATA_TYPE = LSB_BIT_STRING
 START_BYTE = 33
 BYTES = 16
 DESCRIPTION = "Flag indicating whether the packet or individual shots passed or failed the various shot quality tests. Reading the flag from right to left with the rightmost bit being bit 0 and the leftmost bit being bit 63 the format of the flag is
 bit 0: packet validity checksum test, (per packet test)
 bit 1: computer software validity checksum test, (per packet test)
 bit 2: frame acquisition vs. tracking mode test. (per frame test)
 bit 3: first shot of the packet is OTS test, (per packet test)
 bits 4 - 23: transmit power test, (per shot test)
 bits 24 - 43: return energy test, (per shot test)
 bits 44 - 63: range test, (per shot test)
 bits 64 - 83: range window test
 bits 84 - 103: range comparison test
 bits 104 - 127: unused
 A 1 indicates the test was failed, 0 indicates the test was passed.
 For the bits that flag each shot, the lower bit corresponds to shot 1 and the higher bit corresponds to shot 20."

OBJECT = BIT_COLUMN
 NAME = PACKET_VALIDITY_CHECKSUM_FLAG
 BIT_DATA_TYPE = UNSIGNED_INTEGER
 START_BIT = 1
 BITS = 1
 DESCRIPTION = "Packet validity checksum test flag bit. Please see 'shot_quality_descriptor_flag' column object for fuller description."
 END_OBJECT = BIT_COLUMN

OBJECT = BIT_COLUMN
 NAME = SOFTWARE_VALIDITY_CHKSM_FLAG
 BIT_DATA_TYPE = UNSIGNED_INTEGER
 START_BIT = 2
 BITS = 1
 DESCRIPTION = "Computer software validity checksum test flag bit. Please see 'shot_quality_descriptor_flag' column object for fuller description."
 END_OBJECT = BIT_COLUMN

OBJECT = BIT_COLUMN
 NAME = ACQ_TRACK_MODE_TEST_FLAG
 BIT_DATA_TYPE = UNSIGNED_INTEGER
 START_BIT = 3

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

BITS                = 1
DESCRIPTION         = "Frame Acquisition vs. Tracking Mode Test flag
bit. Please see 'shot_quality_descriptor_flag' column object for fuller
description."
END_OBJECT         = BIT_COLUMN

OBJECT             = BIT_COLUMN
NAME              = FIRST_SHOT_OTS_FLAG
BIT_DATA_TYPE     = UNSIGNED_INTEGER
START_BIT        = 4
BITS             = 1
DESCRIPTION       = "First shot in the packet is OTS test flag bit.
Please see 'shot_quality_descriptor_flag' column object for fuller
description."
END_OBJECT         = BIT_COLUMN

OBJECT             = BIT_COLUMN
NAME              = TRANSMIT_POWER_TEST
BIT_DATA_TYPE     = UNSIGNED_INTEGER
START_BIT        = 5
BITS             = 20
DESCRIPTION       = "Transmit power test flag bits. Please see
'shot_quality_descriptor_flag' column object for fuller description."
END_OBJECT         = BIT_COLUMN

OBJECT             = BIT_COLUMN
NAME              = RETURN_ENERGY_TEST
BIT_DATA_TYPE     = UNSIGNED_INTEGER
START_BIT        = 25
BITS             = 20
DESCRIPTION       = "Return energy test flag bits. Please see
'shot_quality_descriptor_flag' column object for fuller description."
END_OBJECT         = BIT_COLUMN

OBJECT             = BIT_COLUMN
NAME              = RANGE_TEST
BIT_DATA_TYPE     = UNSIGNED_INTEGER
START_BIT        = 45
BITS             = 20
DESCRIPTION       = "Range test flag bits. Please see
'shot_quality_descriptor_flag' column object for fuller description."
END_OBJECT         = BIT_COLUMN

OBJECT             = BIT_COLUMN
NAME              = RANGE_WINDOW_TEST
BIT_DATA_TYPE     = UNSIGNED_INTEGER
START_BIT        = 65
BITS             = 20
DESCRIPTION       = "Range window test flag bits. Please see
'shot_quality_descriptor_flag' column object for fuller description."
END_OBJECT         = BIT_COLUMN

OBJECT             = BIT_COLUMN
NAME              = RANGE_COMPARISON_TEST

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

BIT_DATA_TYPE      = UNSIGNED_INTEGER
START_BIT          = 85
BITS               = 20
DESCRIPTION        = "Range comparison test flag bits. Please see
'shot_quality_descriptor_flag' column object for fuller description."
END_OBJECT         = BIT_COLUMN

END_OBJECT         = COLUMN

OBJECT             = COLUMN
NAME               = SHOT_PLANETARY_RADIUS
DATA_TYPE          = MSB_UNSIGNED_INTEGER
START_BYTE         = 49
BYTES              = 80
ITEMS              = 20
ITEM_BYTES         = 4
UNIT               = 'CENTIMETERS'
DESCRIPTION        = "Array of 20 MOLA planetary radius values in the
data frame; the distance from the center of Mars to the point on the
surface of Mars described by the MOLA range; per shot."
END_OBJECT         = COLUMN

OBJECT             = COLUMN
NAME               = FRAME_PLANETARY_RADIUS
DATA_TYPE          = MSB_UNSIGNED_INTEGER
START_BYTE         = 129
BYTES              = 4
UNIT               = 'CENTIMETERS'
DESCRIPTION        = "Planetary radius associated with MOLA data frame
mid-point; the distance from the center of Mars to the point on the
surface of Mars described by the frame mid-point range."
END_OBJECT         = COLUMN

OBJECT             = COLUMN
NAME               = RIGHT_ASCENSION
DATA_TYPE          = MSB_INTEGER
START_BYTE         = 133
BYTES              = 4
UNIT               = 'MILLIRADIANS'
DESCRIPTION        = "Right ascension angle of the MOLA instrument at
data frame mid-point."
END_OBJECT         = COLUMN

OBJECT             = COLUMN
NAME               = DECLINATION
DATA_TYPE          = MSB_INTEGER
START_BYTE         = 137
BYTES              = 4
UNIT               = 'MILLIRADIANS'
DESCRIPTION        = "Declination angle of the MOLA instrument at data
frame mid-point."
END_OBJECT         = COLUMN

OBJECT             = COLUMN

```


MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

NAME = TWIST
 DATA_TYPE = MSB_INTEGER
 START_BYTE = 141
 BYTES = 4
 UNIT = 'MILLIRADIANS'
 DESCRIPTION = "Twist angle of the MOLA instrument at data frame mid-point."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = CORR_RECV_PULSE_ENRGY
 DATA_TYPE = MSB_UNSIGNED_INTEGER
 START_BYTE = 145
 BYTES = 40
 ITEMS = 20
 ITEM_BYTES = 2
 UNIT = 'ATTOJOULES'
 DESCRIPTION = "Corrected surface-scattered return energy measured by first MOLA channel to trigger (an array of 20 values for the data frame). Saturation of energy detector may occur (see RECV_PULSE_ENERGY_COUNTS)."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = SURF_REFLECTIVITY
 DATA_TYPE = MSB_UNSIGNED_INTEGER
 START_BYTE = 185
 BYTES = 40
 ITEMS = 20
 ITEM_BYTES = 2
 DESCRIPTION = "Relative Martian surface reflectivity * atmospheric transmittance values, one per shot; stored as a pure fraction * 10**5."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = TRIGGER_CHANNEL_NUMBER
 DATA_TYPE = UNSIGNED_INTEGER
 START_BYTE = 225
 BYTES = 20
 ITEMS = 20
 ITEM_BYTES = 1
 DESCRIPTION = "Channel number of first MOLA channel to trigger (array of 20 values for data frame)."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = PULSE_WIDTH
 DATA_TYPE = MSB_UNSIGNED_INTEGER
 START_BYTE = 245
 BYTES = 40
 ITEMS = 20
 ITEM_BYTES = 2
 UNIT = 'NANOSECONDS * 10'

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

DESCRIPTION = "The time between threshold crossings of the detected pulse, one per shot, 20 2-byte values. Detector saturation may occur (see RECV_PULSE_WIDTH_COUNTS)."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = RECV_OPTICAL_PULSE_WIDTH
 DATA_TYPE = MSB_UNSIGNED_INTEGER
 START_BYTE = 285
 BYTES = 40
 ITEMS = 20
 ITEM_BYTES = 2
 UNIT = 'NANOSECONDS * 10'
 DESCRIPTION = "Received optical pulse width, corrected for filter characteristics and threshold settings, as determined by the receiver model (an array of 20 values for the data frame). The pulse width provides an estimate of target slope and/or roughness, assuming linear detector response and nadir-looking geometry."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = PARALLAX_DELTA_LATITUDE
 DATA_TYPE = MSB_INTEGER
 START_BYTE = 325
 BYTES = 4
 ITEMS = 1
 UNIT = 'DEGREES*(10**9) PER METER'
 DESCRIPTION = "Change in latitude with respect to planetary radius at frame midpoint due to parallax."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = PARALLAX_DELTA_LONGITUDE
 DATA_TYPE = MSB_INTEGER
 START_BYTE = 329
 BYTES = 4
 UNIT = 'DEGREES*(10**9) PER METER'
 DESCRIPTION = "Change in longitude with respect to planetary radius at frame midpoint due to parallax."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = CROSSOVER_RESIDUAL
 DATA_TYPE = MSB_INTEGER
 START_BYTE = 333
 BYTES = 4
 UNIT = 'CENTIMETERS'
 DESCRIPTION = "Crossover residual of planetary radius with respect to MOLA database at frame midpoint."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = FRAME_LAT_LON
 DATA_TYPE = MSB_INTEGER

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

START_BYTE = 337
 BYTES = 8
 ITEMS = 2
 ITEM_BYTES = 4
 UNIT = 'DEGREES * (10**6)'
 DESCRIPTION = "The areocentric latitude and the East longitude, IAU1991, of the intersection point between the frame mid-point shot and the Mars surface; from Precision Orbit data; 2 4-byte values."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = LASER_TRANSMIT_POWER
 DATA_TYPE = MSB_UNSIGNED_INTEGER
 START_BYTE = 345
 BYTES = 40
 ITEMS = 20
 ITEM_BYTES = 2
 UNIT = 'MILLIJOULES * 100'
 DESCRIPTION = "MOLA laser transmitted pulse energy (array of 20 values for data frame)."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = SHOT_CLASSIFICATION_CODE
 DATA_TYPE = MSB_INTEGER
 START_BYTE = 385
 BYTES = 40
 ITEMS = 20
 ITEM_BYTES = 2
 DESCRIPTION = "Shot classification: 0=false trigger or no trigger; 1=probable ground trigger; other values unassigned."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = CHANNEL_BACKGROUND_NOISE_CTS
 DATA_TYPE = MSB_UNSIGNED_INTEGER
 START_BYTE = 425
 BYTES = 32
 ITEMS = 8
 ITEM_BYTES = 4
 UNIT = 'COUNTS'
 DESCRIPTION = "Background noise levels in the MOLA channels at half-frame rate; array of 8 four-byte values where array elements 1-4 are 1st half-frame values for channels 1-4 and array elements 5-8 are 2nd half-frame values for channel 1-4."
 END_OBJECT = COLUMN

OBJECT = COLUMN
 NAME = RANGE_DELAY
 DATA_TYPE = MSB_UNSIGNED_INTEGER
 START_BYTE = 457
 BYTES = 4
 UNIT = 'CENTIMETERS'
 DESCRIPTION = "Frame value of range gate delay (to beginning of

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

    range window)."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = RANGE_WIDTH
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 461
BYTES               = 4
UNIT                = 'CENTIMETERS'
DESCRIPTION         = "Frame value of range gate width."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = CHANNEL_THRESHOLD_SETTINGS
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 465
BYTES               = 16
ITEMS               = 8
ITEM_BYTES         = 2
UNIT                = 'MILLIVOLTS'
DESCRIPTION         = "Threshold settings for the 4 MOLA channels; at
    half-frame rate; array of 8 two-byte values where array elements 1-4
    are 1st half-frame values for channels 1-4 and array elements 5-8 are
    2nd half-frame values for channel 1-4."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = RECEIVER_CHAN_MASK
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 481
BYTES               = 2
DESCRIPTION         = "The receiver channel mask status; set to the
    value read from the ATLMOD sent by the altimeter electronics; the mask
    setting indicates which channels are commanded on and off."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = ALGORITHM_WORD_MIN_HITS
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 483
BYTES               = 2
DESCRIPTION         = "The minimum shot hit count value required for a
    matched filter channel to trigger; MIN_HITS value set in algorithm from
    the previous data frame."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = ALGORITHM_WORD_HIT_COUNT
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 485
BYTES               = 2
DESCRIPTION         = "Current value from the active data frame, showing
    the number of hits counted in the possible 20 shot hits in the single
    frame or the number of hits summed over the possible 100 shots when in

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

the 5-frame mode. Tracking algorithm performance indicator. If in the acquisition mode, this field will contain the number of shot hits from a possible 80 shots within the 4 frame acquisition window."

```

END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = FRAME_COUNTER
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 487
BYTES               = 2
DESCRIPTION         = "The frame counter value is set from the previous
data frame tracking algorithm operation."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = TRIGGER_CHANNEL
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 489
BYTES               = 2
DESCRIPTION         = "The first channel triggering at or above the
minimum hit count is set from the previous data frame tracking
algorithm operation."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = FRAME_INDEX
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 491
BYTES               = 2
DESCRIPTION         = "Frame number (among seven frames produced from
the MOLA telemetry packet) generated in Ground Data System processing."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = PACKET_SOURCE_HEADER
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 493
BYTES               = 8
ITEMS               = 2
ITEM_BYTES         = 4
DESCRIPTION         = "The header put on the MOLA telemetry packet by
the Payload Data System."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = TIME_CODE_SECONDS
DATA_TYPE           = MSB_INTEGER
START_BYTE         = 501
BYTES               = 4
UNIT                = 'SECONDS'
DESCRIPTION         = "The whole portion of the packet time referenced
to J2000 in Elapsed Time seconds -- may be a negative number. The time
is obtained from the Payload Data System supplied coarse time code that
is generated at the time of the MOLA packet collection."

```

```

END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = PKT_TIME_CODE_MILLISECONDS
DATA_TYPE           = MSB_INTEGER
START_BYTE         = 505
BYTES               = 2
UNIT                = 'MILLISECONDS'
DESCRIPTION         = "The fractional portion of the packet time
referenced to J2000 in Elapsed Time seconds * 1000 -- may be a negative
number. The time is obtained from the Payload Data System supplied
coarse time code that is generated at the time of the MOLA packet
collection."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = PKT_FINE_TIME
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 507
BYTES               = 2
UNIT                = 'COUNTS'
DESCRIPTION         = "MOLA-generated fine time counter."
END_OBJECT          = COLUMN
    
```

C.3 Contents of the MOLA PEDRENG1.FMT File

```

OBJECT              = COLUMN
NAME                = COMPUTER_MEMORY_TEMPERATURE
DATA_TYPE           = MSB_SIGNED_INTEGER
START_BYTE         = 509
BYTES               = 2
UNIT                = 'DEGREES CELSIUS * 100'
MINIMUM            = 0
MAXIMUM            = 7203
DESCRIPTION         = "The computer memory temperature."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = COMPUTER_CPU_TEMPERATURE
DATA_TYPE           = MSB_SIGNED_INTEGER
START_BYTE         = 511
BYTES               = 2
UNIT                = 'DEGREES CELSIUS * 100'
MINIMUM            = 0
MAXIMUM            = 7203
DESCRIPTION         = "The computer CPU temperature."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = POWER_SUPPLY_TEMPERATURE
DATA_TYPE           = MSB_SIGNED_INTEGER
START_BYTE         = 513
BYTES               = 2
    
```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

UNIT                = 'DEGREES CELSIUS * 100'
MINIMUM             = 0
MAXIMUM             = 7203
DESCRIPTION         = "The power supply temperature."
END_OBJECT          = COLUMN

```

```

OBJECT              = COLUMN
NAME                 = COMPUTER_I/O_TEMPERATURE
DATA_TYPE           = MSB_SIGNED_INTEGER
START_BYTE          = 515
BYTES               = 2
UNIT                = 'DEGREES CELSIUS * 100'
MINIMUM             = 0
MAXIMUM             = 7203
DESCRIPTION         = "The computer I/O temperature."
END_OBJECT          = COLUMN

```

```

OBJECT              = COLUMN
NAME                 = LASER_DIODE_ARRAY_TEMPERATURE
DATA_TYPE           = MSB_SIGNED_INTEGER
START_BYTE          = 517
BYTES               = 2
UNIT                = 'DEGREES CELSIUS * 100'
MINIMUM             = 0
MAXIMUM             = 7203
DESCRIPTION         = "The LASER diode array temperature."
END_OBJECT          = COLUMN

```

```

OBJECT              = COLUMN
NAME                 = LASER_DIODE_DRIVE_ELECS_TEMP
DATA_TYPE           = MSB_SIGNED_INTEGER
START_BYTE          = 519
BYTES               = 2
UNIT                = 'DEGREES CELSIUS * 100'
MINIMUM             = 0
MAXIMUM             = 7203
DESCRIPTION         = "The LASER diode drive electronics
temperature."
END_OBJECT          = COLUMN

```

```

OBJECT              = COLUMN
NAME                 = OPTICAL_TEST_SOURCE_LED_TEMP
DATA_TYPE           = MSB_SIGNED_INTEGER
START_BYTE          = 521
BYTES               = 2
UNIT                = 'DEGREES CELSIUS * 100'
MINIMUM             = 0
MAXIMUM             = 7203
DESCRIPTION         = "The optical test source LED temperature."
END_OBJECT          = COLUMN

```

```

OBJECT              = COLUMN
NAME                 = HUNDRED_MHZ_OSCILLATOR_TEMP
DATA_TYPE           = MSB_SIGNED_INTEGER
START_BYTE          = 523
BYTES               = 2
UNIT                = 'DEGREES CELSIUS * 100'
MINIMUM             = 0
MAXIMUM             = 7203

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

DESCRIPTION          = "The 100 MHz Oscillator temperature."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = START_DETECTOR_TEMPERATURE
DATA_TYPE            = MSB_SIGNED_INTEGER
START_BYTE           = 525
BYTES                = 2
UNIT                 = 'DEGREES CELSIUS * 100'
MINIMUM              = 0
MAXIMUM              = 7203
DESCRIPTION          = "The start detector temperature."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = OUTSIDE_DETECTOR_HOUSING_TEMP
DATA_TYPE            = MSB_SIGNED_INTEGER
START_BYTE           = 527
BYTES                = 2
UNIT                 = 'DEGREES CELSIUS * 100'
MINIMUM              = 0
MAXIMUM              = 7203
DESCRIPTION          = "The outside detector housing temperature."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = LASR_RADIATR_OPP_OPT_PORT_TEMP
DATA_TYPE            = MSB_SIGNED_INTEGER
START_BYTE           = 529
BYTES                = 2
UNIT                 = 'DEGREES CELSIUS * 100'
MINIMUM              = 0
MAXIMUM              = 7203
DESCRIPTION          = "The LASER radiator opposite output port
  temperature."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = LSER_RADIATOR_OUTPUT_PORT_TEMP
DATA_TYPE            = MSB_SIGNED_INTEGER
START_BYTE           = 531
BYTES                = 2
UNIT                 = 'DEGREES CELSIUS * 100'
MINIMUM              = 0
MAXIMUM              = 7203
DESCRIPTION          = "The LASER radiator output port
  temperature."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = INTERFACE_PLATE_HOT_FOOT_TEMP
DATA_TYPE            = MSB_SIGNED_INTEGER
START_BYTE           = 533
BYTES                = 2
UNIT                 = 'DEGREES CELSIUS * 100'
MINIMUM              = 0
MAXIMUM              = 7203
DESCRIPTION          = "The interface plate temperature."
END_OBJECT           = COLUMN

```



```

OBJECT          = COLUMN
NAME            = HONEYCOMB_PANEL_TEMPERATURE
DATA_TYPE      = MSB_SIGNED_INTEGER
START_BYTE     = 535
BYTES          = 2
UNIT           = 'DEGREES CELSIUS * 100'
MINIMUM        = 0
MAXIMUM        = 7203
DESCRIPTION    = "The honeycomb panel temperature."
END_OBJECT     = COLUMN
    
```

C.4 Contents of the MOLA PEDRENG2.FMT Format File

```

OBJECT          = COLUMN
NAME            = ELECTRONICS_BOX_TOP_SC_THRMSTR
DATA_TYPE      = MSB_SIGNED_INTEGER
START_BYTE     = 509
BYTES          = 2
UNIT           = 'DEGREES CELSIUS * 100'
MINIMUM        = 0
MAXIMUM        = 7203
DESCRIPTION    = "The electronics box top near spacecraft
  thermistor temperature."
END_OBJECT     = COLUMN
    
```

```

OBJECT          = COLUMN
NAME            = LASER_CASE_HOT_FOOT_TEMP
DATA_TYPE      = MSB_SIGNED_INTEGER
START_BYTE     = 511
BYTES          = 2
UNIT           = 'DEGREES CELSIUS * 100'
MINIMUM        = 0
MAXIMUM        = 7203
DESCRIPTION    = "The LASER case near 'hot foot' temperature."
END_OBJECT     = COLUMN
    
```

```

OBJECT          = COLUMN
NAME            = PLUS_28_VOLT_VOLTAGE_MONITOR
DATA_TYPE      = MSB_UNSIGNED_INTEGER
START_BYTE     = 513
BYTES          = 2
UNIT           = 'MILLIVOLTS'
MINIMUM        = 0
MAXIMUM        = 63531
DESCRIPTION    = "The 28-volt monitor reading."
END_OBJECT     = COLUMN
    
```

```

OBJECT          = COLUMN
NAME            = REFERENCE_VOLTAGE_MONITOR
DATA_TYPE      = MSB_UNSIGNED_INTEGER
START_BYTE     = 515
BYTES          = 2
UNIT           = 'MILLIVOLTS'
MINIMUM        = 0
MAXIMUM        = 5000
    
```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

DESCRIPTION          = "The reference voltage monitor reading."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = PLUS_12_VOLT_VOLTAGE_MONITOR
DATA_TYPE            = MSB_UNSIGNED_INTEGER
START_BYTE           = 517
BYTES                = 2
UNIT                 = 'MILLIVOLTS'
MINIMUM              = 0
MAXIMUM              = 27346
DESCRIPTION          = "The 12-volt voltage monitor reading."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = PLUS_24_VOLT_VOLTAGE_MONITOR
DATA_TYPE            = MSB_UNSIGNED_INTEGER
START_BYTE           = 519
BYTES                = 2
UNIT                 = 'MILLIVOLTS'
MINIMUM              = 0
MAXIMUM              = 65535
DESCRIPTION          = "The 24-volt voltage monitor reading."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = PLUS_5_VOLT_VOLTAGE_MONITOR
DATA_TYPE            = MSB_UNSIGNED_INTEGER
START_BYTE           = 521
BYTES                = 2
UNIT                 = 'MILLIVOLTS'
MINIMUM              = 0
MAXIMUM              = 11320
DESCRIPTION          = "The 5-volt voltage monitor reading."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = MINUS_12_VOLT_VOLTAGE_MONITOR
DATA_TYPE            = MSB_UNSIGNED_INTEGER
START_BYTE           = 523
BYTES                = 2
UNIT                 = 'MILLIVOLTS'
MINIMUM              = 0
MAXIMUM              = 27149
DESCRIPTION          = "The negative-12-volt voltage monitor
reading."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = LASER_THERMAL_CURRENT_MONITOR
DATA_TYPE            = MSB_UNSIGNED_INTEGER
START_BYTE           = 525
BYTES                = 2
UNIT                 = 'MILLIAMPS * 10'
MINIMUM              = 0
MAXIMUM              = 8462
DESCRIPTION          = "The LASER/thermal current monitor reading."
END_OBJECT           = COLUMN

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

OBJECT          = COLUMN
NAME           = MINUS_5_VOLT_VOLTAGE_MONITOR
DATA_TYPE      = MSB_UNSIGNED_INTEGER
START_BYTE     = 527
BYTES          = 2
UNIT           = 'MILLIVOLTS'
MINIMUM        = 0
MAXIMUM        = 11330
DESCRIPTION    = "The negative-5-volt voltage monitor
  reading."
END_OBJECT     = COLUMN

OBJECT          = COLUMN
NAME           = POWER_SUPPLY_CURRENT_MONITOR
DATA_TYPE      = MSB_UNSIGNED_INTEGER
START_BYTE     = 529
BYTES          = 2
UNIT           = 'MILLIAMPS * 10'
MINIMUM        = 0
MAXIMUM        = 8263
DESCRIPTION    = "The power supply current monitor reading."
END_OBJECT     = COLUMN

OBJECT          = COLUMN
NAME           = HIGH_VOLTAGE_MONITOR
DATA_TYPE      = MSB_UNSIGNED_INTEGER
START_BYTE     = 531
BYTES          = 2
UNIT           = 'DECIVOLTS'
MINIMUM        = 0
MAXIMUM        = 12349
DESCRIPTION    = "The high voltage monitor reading."
END_OBJECT     = COLUMN

OBJECT          = COLUMN
NAME           = MINUS_12_VOLT_CURRENT_MONITOR
DATA_TYPE      = MSB_UNSIGNED_INTEGER
START_BYTE     = 533
BYTES          = 2
UNIT           = 'MILLIAMPS * 100'
MINIMUM        = 0
MAXIMUM        = 24424
DESCRIPTION    = "The negative-12-volt current monitor
  reading."
END_OBJECT     = COLUMN

OBJECT          = COLUMN
NAME           = PLUS_12_VOLT_CURRENT_MONITOR
DATA_TYPE      = MSB_UNSIGNED_INTEGER
START_BYTE     = 535
BYTES          = 2
UNIT           = 'MILLIAMPS * 100'
MINIMUM        = 0
MAXIMUM        = 24395
DESCRIPTION    = "The 12-volt current monitor reading."
END_OBJECT     = COLUMN

```

C.5 Contents of the MOLA PEDRENG3.FMT Format File

```

OBJECT          = COLUMN
NAME            = MINUS_5_VOLT_CURRENT_MONITOR
DATA_TYPE      = MSB_UNSIGNED_INTEGER
START_BYTE     = 509
BYTES          = 2
UNIT           = 'MILLIAMPS * 100'
MINIMUM        = 0
MAXIMUM        = 25199
DESCRIPTION    = "The negative-5-volt current monitor
  reading."
END_OBJECT     = COLUMN

OBJECT          = COLUMN
NAME            = PLUS_5_VOLT_CURRENT_MONITOR
DATA_TYPE      = MSB_UNSIGNED_INTEGER
START_BYTE     = 511
BYTES          = 2
UNIT           = 'MILLIAMPS * 10'
MINIMUM        = 0
MAXIMUM        = 13537
DESCRIPTION    = "The 5-volt current monitor reading."
END_OBJECT     = COLUMN

OBJECT          = COLUMN
NAME            = CURRENT_STATUS_REGISTER_VALUE
DATA_TYPE      = UNSIGNED_INTEGER
START_BYTE     = 513
BYTES          = 1
MINIMUM        = 0
MAXIMUM        = 255
DESCRIPTION    = "Value read from STATUS register at end of
  packet collection cycle. Read STATUS register and store lower 8
  bits. MSnibble = SEU counter value."
END_OBJECT     = COLUMN

OBJECT          = COLUMN
NAME            = SOFTWARE_VERSION_NUMBER
DATA_TYPE      = UNSIGNED_INTEGER
START_BYTE     = 514
BYTES          = 1
MINIMUM        = 0
MAXIMUM        = 255
DESCRIPTION    = "The software version number in the telemetry
  packet in 4.4 bit format."
END_OBJECT     = COLUMN

OBJECT          = COLUMN
NAME            = FLAG_WORD
DATA_TYPE      = MSB_UNSIGNED_INTEGER
START_BYTE     = 515
BYTES          = 2
MINIMUM        = 0
MAXIMUM        = 65535
DESCRIPTION    = "RAM block test flag word. Memory test
  results. Bit representation of the results of the RAM write/read/
  verify block test performed after a CPU reset (HOT or COLD start)."

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

MSB (#15) represents the memory block from 7800h to 7FFFh; LSB (#0) from 0000h to 7FFh. 1 = error detected, 0 = block O.K."

```

END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = STATUS_FLAGS
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 517
BYTES               = 4
ITEMS               = 2
ITEM_BYTES         = 2
MINIMUM            = 0
MAXIMUM            = 65535
DESCRIPTION         = "Values of SFLAG1 and SFLAG2 stored at packet
  completion. Each flag represents four 4 bit words. B[0] = byte 0;
  B[1] = byte 1; B[2] = byte 2; B[3] = byte 3. The meanings of the
  individual bit settings is in Appendix A of the MOLA Flight
  Software Users' Guide."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = SOFTWARE_VALIDITY_CHECKSUM
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 521
BYTES               = 2
MINIMUM            = 0
MAXIMUM            = 65535
DESCRIPTION         = "Checksum (end-around-carry, word adds)
  calculated using start address and length from Parameter Table.
  One word calculated using (CHKLEN/2)# of word end-around-carry
  additions start at word # (CHKSTART/2). Note: CHKLEN and CHKSTART
  exist in the parameter table and are BYTE length and BYTE address
  or offset. B[0] is MSByte and B[1] is LSByte of software validity
  checksum."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = RECEIVED_COMMAND_COUNT
DATA_TYPE           = UNSIGNED_INTEGER
START_BYTE         = 523
BYTES               = 1
MINIMUM            = 0
MAXIMUM            = 255
DESCRIPTION         = "Number of commands received in the DMA
  buffer, i.e., number separated by CMD_START bits set, never
  cleared, init = 0. Number of CMD_START bits set in the commands
  received buffer. Only look at the number of commands received
  during that RTI interval. Count performed during RTI 4ms 'quiet
  time'. Counter starts at 0 from a HOT/COLD start, counts up and
  rolls over from 0FFh to 00h."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = COMMAND_ERROR_COUNT
DATA_TYPE           = UNSIGNED_INTEGER
START_BYTE         = 524
BYTES               = 1
MINIMUM            = 0
MAXIMUM            = 255

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

DESCRIPTION          = "Number of invalid MOLA specific commands
                        received, never cleared, init = 0. Command errors counter works
                        the same way as Received command count (see above), except, this
                        counts the # of command errors, defined as wrong instrument id,
                        wrong command type bit, parity error in 1st word of multi-word
                        command, incorrect opcode word (NOT 0x2120) in multi-word
                        command, or unknown single-word command."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = TRANSMITTER_THRESHOLD_SETTING
DATA_TYPE            = MSB_UNSIGNED_INTEGER
START_BYTE           = 525
BYTES                 = 1
MINIMUM              = 0
MAXIMUM              = 255
DESCRIPTION           = "Value of XMITDA from Parameter table, stored
                        at packet completion. LSB is equivalent to 1 mv. This byte reports
                        the value of XMITDA from PARAM_TABLE. It is stored in the packet
                        at the end of the packet collection cycle."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = RANGE_TRACKING_STATUS
DATA_TYPE            = UNSIGNED_INTEGER
START_BYTE           = 526
BYTES                 = 1
MINIMUM              = 0
MAXIMUM              = 255
DESCRIPTION           = "MSB = OTS_FIRE value, bits 7654321, 1 =
                        TRACKING, 0 = ACQ. MSB (#7) is the LSB of OST_FIRE from
                        PARAM_TABLE, stored at the end of the packet collection cycle. It
                        is the value used to determine the firing status of the Optical
                        Test Shot for the first shot of the packet cycle. Bits 6-0
                        represent frames 7-1 tracking status. 0 means that the software
                        was in acquisition mode for that frame, while 1 represents
                        tracking mode."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = SPARE
DATA_TYPE            = MSB_UNSIGNED_INTEGER
START_BYTE           = 527
BYTES                 = 2
DESCRIPTION           = "Two unused bytes."
END_OBJECT           = COLUMN

OBJECT               = COLUMN
NAME                 = RANGE_GATE_TRACKER_ARRAY
DATA_TYPE            = MSB_UNSIGNED_INTEGER
START_BYTE           = 529
BYTES                 = 8
ITEMS                 = 4
ITEM_BYTES           = 2
MINIMUM              = 0
MAXIMUM              = 255
DESCRIPTION           = "The range gate tracker array information is
                        actually 48 bytes of data. These 8 bytes represent the first 8 in
                        the array. Subsequent bytes appear in Frame 4 and 5 engineering
    
```

data. 73.728 km, 48 HISTOGRAM bins starting at HSTART. 48 sequential bins of the ranging histogram, stored after the sixth shot is collected, but before the ranging algorithm is executed on that frame's data. HSTART, from PARAM_TABLE, with the LSB cleared is the number of the first bin stored. Bins are represented as bytes, but they are stored as words. Therefore, the bytes are swapped. HSTART correction: HSTART = HSTART + 0xFFFFE. The following denotes the range of each bin for each data byte (B[x]). C = 1.536km.

```

B[ 0] : (HSTART + 1) * C; B[ 1] : (HSTART + 0) * C;
B[ 2] : (HSTART + 3) * C; B[ 3] : (HSTART + 2) * C;
B[ 4] : (HSTART + 5) * C; B[ 5] : (HSTART + 4) * C;
B[ 6] : (HSTART + 7) * C; B[ 7] : (HSTART + 6) * C;
B[ 8] : (HSTART + 9) * C; B[ 9] : (HSTART + 8) * C;
B[10] : (HSTART + 11) * C; B[11] : (HSTART + 10) * C;
B[12] : (HSTART + 13) * C; B[13] : (HSTART + 12) * C;
B[14] : (HSTART + 15) * C; B[15] : (HSTART + 14) * C;
B[16] : (HSTART + 17) * C; B[17] : (HSTART + 16) * C;
B[18] : (HSTART + 19) * C; B[19] : (HSTART + 18) * C;
B[20] : (HSTART + 21) * C; B[21] : (HSTART + 20) * C;
B[22] : (HSTART + 23) * C; B[23] : (HSTART + 22) * C;
B[24] : (HSTART + 25) * C; B[25] : (HSTART + 24) * C;
B[26] : (HSTART + 27) * C; B[27] : (HSTART + 26) * C;
B[28] : (HSTART + 29) * C; B[29] : (HSTART + 28) * C;
B[30] : (HSTART + 31) * C; B[31] : (HSTART + 30) * C;
B[32] : (HSTART + 33) * C; B[33] : (HSTART + 32) * C;
B[34] : (HSTART + 35) * C; B[35] : (HSTART + 34) * C;
B[36] : (HSTART + 37) * C; B[37] : (HSTART + 36) * C;
B[38] : (HSTART + 39) * C; B[39] : (HSTART + 38) * C;
B[40] : (HSTART + 41) * C; B[41] : (HSTART + 40) * C;
B[42] : (HSTART + 43) * C; B[43] : (HSTART + 42) * C;
B[44] : (HSTART + 45) * C; B[45] : (HSTART + 44) * C;
B[46] : (HSTART + 47) * C; B[47] : (HSTART + 46) * C"
END_OBJECT          = COLUMN

```

C.6 Contents of the MOLA PEDRENG4.FMT Format File

```

OBJECT          = COLUMN
NAME           = RANGE_GATE_TRACKER_ARRAY
DATA_TYPE     = MSB_UNSIGNED_INTEGER
START_BYTE    = 509
BYTES        = 28
ITEMS       = 14
ITEM_BYTES  = 2
MINIMUM     = 0
MAXIMUM     = 255
DESCRIPTION  = "The range gate tracker array information is
  actually 48 bytes of data. These 28 bytes represent bytes 9 - 36
  (counting from 1) in the array. Previous and subsequent bytes
  appear in Frame 3 and 5 engineering data, respectively. 73.728
  km, 48 HISTOGRAM bins starting at HSTART. 48 sequential bins of
  the ranging histogram, stored after the sixth shot is collected,
  but before the ranging algorithm is executed on that frame's data.
  HSTART, from PARAM_TABLE, with the LSB cleared is the number of
  the first bin stored. Bins are represented as bytes, but they are
  stored as words. Therefore, the bytes are swapped. HSTART

```

correction: $HSTART = HSTART + 0xFFFFE$. The following denotes the range of each bin for each data byte ($B[x]$). $C = 1.536\text{km}$.

```

B[ 0] : (HSTART + 1) * C; B[ 1] : (HSTART + 0) * C;
B[ 2] : (HSTART + 3) * C; B[ 3] : (HSTART + 2) * C;
B[ 4] : (HSTART + 5) * C; B[ 5] : (HSTART + 4) * C;
B[ 6] : (HSTART + 7) * C; B[ 7] : (HSTART + 6) * C;
B[ 8] : (HSTART + 9) * C; B[ 9] : (HSTART + 8) * C;
B[10] : (HSTART + 11) * C; B[11] : (HSTART + 10) * C;
B[12] : (HSTART + 13) * C; B[13] : (HSTART + 12) * C;
B[14] : (HSTART + 15) * C; B[15] : (HSTART + 14) * C;
B[16] : (HSTART + 17) * C; B[17] : (HSTART + 16) * C;
B[18] : (HSTART + 19) * C; B[19] : (HSTART + 18) * C;
B[20] : (HSTART + 21) * C; B[21] : (HSTART + 20) * C;
B[22] : (HSTART + 23) * C; B[23] : (HSTART + 22) * C;
B[24] : (HSTART + 25) * C; B[25] : (HSTART + 24) * C;
B[26] : (HSTART + 27) * C; B[27] : (HSTART + 26) * C;
B[28] : (HSTART + 29) * C; B[29] : (HSTART + 28) * C;
B[30] : (HSTART + 31) * C; B[31] : (HSTART + 30) * C;
B[32] : (HSTART + 33) * C; B[33] : (HSTART + 32) * C;
B[34] : (HSTART + 35) * C; B[35] : (HSTART + 34) * C;
B[36] : (HSTART + 37) * C; B[37] : (HSTART + 36) * C;
B[38] : (HSTART + 39) * C; B[39] : (HSTART + 38) * C;
B[40] : (HSTART + 41) * C; B[41] : (HSTART + 40) * C;
B[42] : (HSTART + 43) * C; B[43] : (HSTART + 42) * C;
B[44] : (HSTART + 45) * C; B[45] : (HSTART + 44) * C;
B[46] : (HSTART + 47) * C; B[47] : (HSTART + 46) * C"
END_OBJECT                = COLUMN

```

C.7 Contents of the MOLA PEDRENG5.FMT Format File

```

OBJECT                = COLUMN
NAME                  = RANGE_GATE_TRACKER_ARRAY
DATA_TYPE             = MSB_UNSIGNED_INTEGER
START_BYTE           = 509
BYTES                 = 12
ITEMS                 = 6
ITEM_BYTES            = 2
MINIMUM               = 0
MAXIMUM               = 255
DESCRIPTION           = "The range gate tracker array information is
  actually 48 bytes of data. These 28 bytes represent bytes 37-48
  (counting from 1) in the array. Previous bytes appear in Frame 3
  and 4 engineering data. 73.728 km, 48 HISTOGRAM bins starting at
  HSTART. 48 sequential bins of the ranging histogram, stored after
  the sixth shot is collected, but before the ranging algorithm is
  executed on that frame's data. HSTART, from PARAM_TABLE, with the
  LSB cleared is the number of the first bin stored. Bins are
  represented as bytes, but they are stored as words. Therefore,
  the bytes are swapped. HSTART correction:  $HSTART = HSTART +
  0xFFFFE$ . The following denotes the range of each bin for each data
  byte ( $B[x]$ ).  $C = 1.536\text{km}$ .
  B[ 0] : (HSTART + 1) * C; B[ 1] : (HSTART + 0) * C;
  B[ 2] : (HSTART + 3) * C; B[ 3] : (HSTART + 2) * C;
  B[ 4] : (HSTART + 5) * C; B[ 5] : (HSTART + 4) * C;
  B[ 6] : (HSTART + 7) * C; B[ 7] : (HSTART + 6) * C;
  B[ 8] : (HSTART + 9) * C; B[ 9] : (HSTART + 8) * C;

```


MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

B[10] : (HSTART + 11) * C; B[11] : (HSTART + 10) * C;
B[12] : (HSTART + 13) * C; B[13] : (HSTART + 12) * C;
B[14] : (HSTART + 15) * C; B[15] : (HSTART + 14) * C;
B[16] : (HSTART + 17) * C; B[17] : (HSTART + 16) * C;
B[18] : (HSTART + 19) * C; B[19] : (HSTART + 18) * C;
B[20] : (HSTART + 21) * C; B[21] : (HSTART + 20) * C;
B[22] : (HSTART + 23) * C; B[23] : (HSTART + 22) * C;
B[24] : (HSTART + 25) * C; B[25] : (HSTART + 24) * C;
B[26] : (HSTART + 27) * C; B[27] : (HSTART + 26) * C;
B[28] : (HSTART + 29) * C; B[29] : (HSTART + 28) * C;
B[30] : (HSTART + 31) * C; B[31] : (HSTART + 30) * C;
B[32] : (HSTART + 33) * C; B[33] : (HSTART + 32) * C;
B[34] : (HSTART + 35) * C; B[35] : (HSTART + 34) * C;
B[36] : (HSTART + 37) * C; B[37] : (HSTART + 36) * C;
B[38] : (HSTART + 39) * C; B[39] : (HSTART + 38) * C;
B[40] : (HSTART + 41) * C; B[41] : (HSTART + 40) * C;
B[42] : (HSTART + 43) * C; B[43] : (HSTART + 42) * C;
B[44] : (HSTART + 45) * C; B[45] : (HSTART + 44) * C;
B[46] : (HSTART + 47) * C; B[47] : (HSTART + 46) * C"
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = HSTART_VALUE_HISTOGRAM_DUMP
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 521
BYTES               = 4
MINIMUM            = 0
MAXIMUM            = 100663296
UNIT               = CENTIMETERS
DESCRIPTION         = "Value of HSTART from Parameter table, stored
                    at packet completion. Stored at the end of the packet collection
                    cycle. HSTART is used to store the Histogram dump bins on the
                    previous frame (2 seconds earlier)."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = SPARE
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 525
BYTES               = 4
ITEMS              = 2
ITEM_BYTES         = 2
DESCRIPTION         = "Four unused bytes."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = VALID_COMMANDS_RECEIVED_COUNT
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 529
BYTES               = 2
MINIMUM            = 0
MAXIMUM            = 65535
DESCRIPTION         = "Number of Time broadcast and Parameter
                    update and channel on/off commands executed, never cleared, init.
                    = 0. This is a 16 bit counter that starts at 0 after a CPU reset
                    and rolls over from 0FFFFh to 0. Valid MOLA specific commands are
                    defined as Channel ON/OFF commands and Parameter Update command
                    All other MOLA specific commands are either flagged as errors or
                    cause a mode change or CPU reset. B[0] = MSByte and B[1] = LSByte

```

```

of valid command counter"
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = MEMORY_DUMP_SEGMENT
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE          = 531
BYTES               = 6
ITEMS               = 3
ITEM_BYTES          = 2
MINIMUM             = 0
MAXIMUM             = 255
DESCRIPTION         = "The memory dump segment is 16 bytes in
length. This portion represents the first 6 bytes. The next 10
bytes are located in the Frame 6 engineering data. 16 bytes read
from memory space starting at ((SEQUENCE & 0x3FFh)*16), dumps 0
- 3FFFh then starts again at 0. Using the lower 11 bits of the
SEQUENCE count, stored in this packet, multiplied by 16 as the
starting byte address, 8 words are read from RAM and stored in
the packet. The following denotes the memory address at each data
byte (B[x]). C =((SEQUENCE & 0x3FFF) *16).
B[ 0] : C+ 1; B[ 1] : C+ 0; B[ 2] : C+ 3; B[ 3] : C+ 2;
B[ 4] : C+ 5; B[ 5] : C+ 4; B[ 6] : C+ 7; B[ 7] : C+ 6;
B[ 8] : C+ 9; B[ 9] : C+ 8; B[10] : C+ 11; B[11] : C+ 10;
B[12] : C+ 13; B[13] : C+ 12; B[14] : C+ 15; B[15] : C+ 14"
END_OBJECT          = COLUMN

```

C.8 Contents of the MOLA PEDRENG6.FMT Format File

```

OBJECT              = COLUMN
NAME                = MEMORY_DUMP_SEGMENT
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE          = 509
BYTES               = 10
ITEMS               = 5
ITEM_BYTES          = 2
MINIMUM             = 0
MAXIMUM             = 255
DESCRIPTION         = "The memory dump segment is 16 bytes in
length. This portion represents the last 10 bytes. The previous
6 bytes are located in the Frame 5 engineering data. 16 bytes read
from memory space starting at ((SEQUENCE & 0x3FFh)*16), dumps 0
- 3FFFh then starts again at 0. Using the lower 11 bits of the
SEQUENCE count, stored in this packet, multiplied by 16 as the
starting byte address, 8 words are read from RAM and stored in
the packet. The following denotes the memory address at each data
byte (B[x]). C =((SEQUENCE & 0x3FFF) *16).
B[ 0] : C+ 1; B[ 1] : C+ 0; B[ 2] : C+ 3; B[ 3] : C+ 2;
B[ 4] : C+ 5; B[ 5] : C+ 4; B[ 6] : C+ 7; B[ 7] : C+ 6;
B[ 8] : C+ 9; B[ 9] : C+ 8; B[10] : C+ 11; B[11] : C+ 10;
B[12] : C+ 13; B[13] : C+ 12; B[14] : C+ 15; B[15] : C+ 14"
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = COMMAND_ECHO
DATA_TYPE           = MSB_UNSIGNED_INTEGER

```

```

START_BYTE          = 519
BYTES               = 16
ITEMS               = 8
ITEM_BYTES          = 2
MINIMUM             = 0
MAXIMUM             = 65535
DESCRIPTION         = "First 8 command words received during
current packet, only complete commands are stored, MOLA specific
commands only. The software attempts to echo all valid commands.
If the command will fit in the room remaining in the buffer, then
it is stored and that much room is removed from that which remains
in the echo buffer. If a command will not fit, then a buffer
overflow is flagged, but subsequent commands that will fit are
still stored in the buffer. The command echo buffer is filled with
zeros at the start of each packet."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = PACKET_VALIDITY_CHECKSUM
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE          = 535
BYTES               = 2
MINIMUM             = 0
MAXIMUM             = 65535
DESCRIPTION         = "Simple 16 bit addition of entire packet
contents upon completion. This location is zeroed for addition.
This word is zeroed, then words 0-539 are added without carry to
a variable that is initially zero. The resulting lower 16 bits
are stored in this location. To verify, read, store, and clear
this location. Then, word add without carry these 540 words and
compare the lower 16 bits with the stored value."
END_OBJECT          = COLUMN

```

C.9 Contents of the MOLA PEDRENG7.FMT Format File

```

OBJECT              = COLUMN
NAME                = OTS_RANGE
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE          = 509
BYTES               = 4
UNIT                = 'CENTIMETERS'
DESCRIPTION         = "The range value of the Optical Test Shot in
the packet."
END_OBJECT          = COLUMN

OBJECT              = COLUMN
NAME                = FIRST_CH_RECEIVED_ENERGY
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE          = 513
BYTES               = 4
UNIT                = 'ATTOJOULES'
DESCRIPTION         = "The first channel received energy for the
Optical Test Shot."
END_OBJECT          = COLUMN

OBJECT              = COLUMN

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

NAME                = SPARE
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 517
BYTES              = 4
DESCRIPTION         = "Unused spare."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME                = OTS_TRANSMIT_POWER
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 521
BYTES              = 4
UNIT                = 'NANOJOULES'
DESCRIPTION         = "The Optical Test Shot transmit power."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME                = OTS_PULSE_WIDTH
DATA_TYPE           = UNSIGNED_INTEGER
START_BYTE         = 525
BYTES              = 1
DESCRIPTION         = "The Optical Test Shot pulse width setting."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME                = OTS_PULSE_AMPLITUDE
DATA_TYPE           = UNSIGNED_INTEGER
START_BYTE         = 526
BYTES              = 1
DESCRIPTION         = "The Optical Test Shot pulse amplitude
setting."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME                = OTS_QUAL_FLAG
DATA_TYPE           = UNSIGNED_INTEGER
START_BYTE         = 527
BYTES              = 1
DESCRIPTION         = "The Optical Test Shot quality flag."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME                = PACKET_TYPE
DATA_TYPE           = UNSIGNED_INTEGER
START_BYTE         = 528
BYTES              = 1
DESCRIPTION         = "Packet type identifier byte. Distinguishes
Science Mode packets from Maintenance Mode packets. Science Mode
is 0 Maintenance Mode = [1 = Status packet, 2 = memory dump].
Values 3 - 255 are reserved for future modes. Modes 0, 1, 2 are
hard coded in the flight software. The packet type value should
be patched when a code patch occurs that affects that mode's
packet content."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME                = AREOCENTRIC_LONGITUDE_OF_SUN
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 529

```

```

BYTES           = 2
UNIT           = 'DEGREES * 100'
MINIMUM        = 0
MAXIMUM        = 36000
DESCRIPTION     = "The angle between the Mars-Sun line and the
line of the equinoxes. Mars seasonal variable."
END_OBJECT     = COLUMN

```

```

OBJECT         = COLUMN
NAME          = SPARE
DATA_TYPE     = UNSIGNED_INTEGER
START_BYTE    = 531
BYTES         = 6
ITEMS         = 6
ITEM_BYTES    = 1
DESCRIPTION   = "Unused spares."
END_OBJECT    = COLUMN

```

C.10 Contents of the MOLA PEDRSEC3.FMT Format File

```

OBJECT         = COLUMN
NAME          = ORBIT_QUALITY_FLAG
DATA_TYPE     = MSB_UNSIGNED_INTEGER
START_BYTE    = 537
BYTES         = 2
DESCRIPTION   = "Flag indicating origin of orbit. A 0 indicates
that JPL is the producer; a 1 or higher indicates that the MOLA Science
Investigation Team is the producer, using the potential model GMM-1
or higher."
END_OBJECT    = COLUMN

```

```

OBJECT         = COLUMN
NAME          = ATTITUDE_FLAG
DATA_TYPE     = MSB_UNSIGNED_INTEGER
START_BYTE    = 539
BYTES         = 2
DESCRIPTION   = "Flag indicating spacecraft attitude data was not
available for all (3) or part (2) of a MOLA frame, in which case ground
location is calculated assuming nadir-pointing geometry."
END_OBJECT    = COLUMN

```

```

OBJECT         = COLUMN
NAME          = FRAME_LOCAL_TIME
DATA_TYPE     = MSB_INTEGER
START_BYTE    = 541
BYTES         = 2
UNIT          = 'RADIANS * (10**4)'
DESCRIPTION   = "The subsolar longitude on Mars at the frame mid-point,
in the range from -Pi to Pi."
END_OBJECT    = COLUMN

```

```

OBJECT         = COLUMN
NAME          = PHASE_ANGLE

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

DATA_TYPE          = MSB_UNSIGNED_INTEGER
START_BYTE        = 543
BYTES             = 2
UNIT              = 'RADIANS * (10**4)'
DESCRIPTION       = "The angle between the vectors from Mars to Mars
  Global Surveyor and from Mars to the Sun at the frame mid-point
  location."
END_OBJECT        = COLUMN

OBJECT            = COLUMN
NAME              = SOLAR_INCIDENCE_ANGLE
DATA_TYPE        = MSB_UNSIGNED_INTEGER
START_BYTE      = 545
BYTES           = 2
UNIT            = 'RADIANS * (10**4)'
DESCRIPTION     = "The angle between the Mars surface normal vector
  and the Sun vector at the frame mid-point location."
END_OBJECT      = COLUMN

OBJECT            = COLUMN
NAME              = EMISSION_ANGLE
DATA_TYPE        = MSB_UNSIGNED_INTEGER
START_BYTE      = 547
BYTES           = 2
UNIT            = 'RADIANS * (10**4)'
DESCRIPTION     = "The angle between the Mars surface normal vector
  and the Mars Global Surveyor vector at the frame mid-point location."
END_OBJECT      = COLUMN

OBJECT            = COLUMN
NAME              = ATMOS_OPACITY
DATA_TYPE        = MSB_UNSIGNED_INTEGER
START_BYTE      = 549
BYTES           = 4
DESCRIPTION     = "The Mars atmospheric opacity Tau; may be
  retrieved from TES data. Nominally 0.5. Stored as a pure number *
  10**6. To calculate surface reflectivity, the reflectivity-transmission
  product should be divided by exp(2* Tau)."
END_OBJECT      = COLUMN

OBJECT            = COLUMN
NAME              = DP_FRAME_TIME
DATA_TYPE        = IEEE_REAL
START_BYTE      = 553
BYTES           = 8
UNIT            = 'SECONDS'
DESCRIPTION     = "The IEEE standard 754-1985 double precision frame
  mid-point time in elapsed time from J2000, in seconds."
END_OBJECT      = COLUMN

OBJECT            = COLUMN
NAME              = RECV_PULSE_ENERGY_COUNTS

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

DATA_TYPE           = UNSIGNED_INTEGER
START_BYTE         = 561
BYTES              = 20
ITEMS              = 20
ITEM_BYTES         = 1
UNIT               = 'COUNTS'
DESCRIPTION        = "The raw pulse energy reading for the trigger
channel; in the range 0-255. (An array of 20 values per frame.)"
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME               = RECV_PULSE_WIDTH_COUNTS
DATA_TYPE          = UNSIGNED_INTEGER
START_BYTE         = 581
BYTES              = 20
ITEMS              = 20
ITEM_BYTES         = 1
UNIT               = 'COUNTS'
DESCRIPTION        = "The raw pulse width reading for the trigger
channel; in the range 0-63. (An array of 20 values per frame.)"
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME               = DELTA_SC_LATITUDE
DATA_TYPE          = MSB_INTEGER
START_BYTE         = 601
BYTES              = 4
UNIT               = 'DEGREES*(10**6)'
DESCRIPTION        = "The average change in spacecraft areocentric latitude
associated with each 20-shot MOLA frame."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME               = DELTA_SC_LONGITUDE
DATA_TYPE          = MSB_INTEGER
START_BYTE         = 605
BYTES              = 4
UNIT               = 'DEGREES*(10**6)'
DESCRIPTION        = "The average change in spacecraft areocentric longitude
associated with each 20-shot MOLA frame."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME               = DELTA_SC_RADIUS
DATA_TYPE          = MSB_INTEGER
START_BYTE         = 609
BYTES              = 4
UNIT               = 'CENTIMETERS'
DESCRIPTION        = "The average change in spacecraft radial distance
associated with each 20-shot MOLA frame."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME               = AREOID_RADIUS

```

MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

DATA_TYPE          = MSB_UNSIGNED_INTEGER
START_BYTE        = 613
BYTES             = 4
UNIT              = 'CENTIMETERS'
DESCRIPTION       = "The radius of the reference areoid at frame
midpoint, with a 3396 kilometer mean radius at the equator. Initially,
the Goddard Mars Model 1 (GMM1) of Smith et al., 1993, with the
coordinate system of IAU1991, is used."
END_OBJECT       = COLUMN

OBJECT            = COLUMN
NAME              = OFF_NADIR_ANGLE
DATA_TYPE        = MSB_INTEGER
START_BYTE      = 617
BYTES           = 4
UNIT            = 'DEGREES * (10**6)'
DESCRIPTION     = "Angle between the transmitted laser shot
direction and areocentric direction, at spacecraft frame mid-point."
END_OBJECT     = COLUMN

OBJECT            = COLUMN
NAME              = ENCODER_BITS
DATA_TYPE        = UNSIGNED_INTEGER
START_BYTE      = 621
BYTES           = 20
ITEMS           = 20
ITEM_BYTES      = 1
DESCRIPTION     = "The start encoder bits (0-3) plus 16*stop encoder
bits (0-3) for each MOLA shot. These bits interpolate the time of the
start and stop detectors to improve shot range precision."
END_OBJECT     = COLUMN

OBJECT            = COLUMN
NAME              = DELTA_AREOID
DATA_TYPE        = MSB_INTEGER
START_BYTE      = 641
BYTES           = 4
UNIT            = 'CENTIMETERS'
DESCRIPTION     = "The average change in reference areoid associated
with each 20-shot MOLA frame."
END_OBJECT     = COLUMN

OBJECT            = COLUMN
NAME              = MOLA_CLOCK_RATE
DATA_TYPE        = MSB_UNSIGNED_INTEGER
START_BYTE      = 645
BYTES           = 4
UNIT            = 'HERTZ'
DESCRIPTION     = "The MOLA clock rate estimated from the fine time
counter drift with respect to the spacecraft clock."
END_OBJECT     = COLUMN

OBJECT            = COLUMN

```


MOLA PRECISION EXPERIMENT DATA RECORD SOFTWARE INTERFACE SPECIFICATION

```

NAME                = MOLA_RANGE
DATA_TYPE           = MSB_UNSIGNED_INTEGER
START_BYTE         = 649
BYTES              = 80
ITEMS              = 20
ITEM_BYTES         = 4
UNIT               = 'CENTIMETERS'
DESCRIPTION        = "MOLA range value per shot; this value is
corrected by the range_correction. Array of 20 four byte values."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME                = RANGE_CORRECTION
DATA_TYPE           = MSB_INTEGER
START_BYTE         = 729
BYTES              = 40
ITEMS              = 20
ITEM_BYTES         = 2
UNIT               = 'CENTIMETERS'
DESCRIPTION        = "Correction to the shot range values due to the
detector response and range walk. Array of 20 two-byte values."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME                = DELTA_LATITUDE
DATA_TYPE           = MSB_INTEGER
START_BYTE         = 769
BYTES              = 4
UNIT               = 'DEGREES *(10**6)'
DESCRIPTION        = "The average change in latitude
associated with each 20-shot MOLA frame."
END_OBJECT         = COLUMN

OBJECT              = COLUMN
NAME                = DELTA_LONGITUDE
DATA_TYPE           = MSB_INTEGER
START_BYTE         = 773
BYTES              = 4
UNIT               = 'DEGREES *(10**6)'
DESCRIPTION        = "The average change in longitude
associated with each 20-shot MOLA frame."
END_OBJECT         = COLUMN

```